

Seater Head 9,30/.366-R54

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-R54
- Manufacturer: TRIEBEL
- Product no.: EU2017510
- Mfr. No.: 3000054V-09.30-R054
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R54
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R054

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 9,30/.366R54. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the optimal performance of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure safe use of the Seater Head by following all instructions.
- Be aware of potential hazards associated with improper handling and usage.
- Always use the product in accordance with the manufacturer's recommendations.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the relevant authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Seater Head.
- Avoid using the Seater Head if it is damaged or worn.
- Ensure that the equipment used with the Seater Head is compatible and in good condition.
- Do not exceed the manufacturer's specifications for bullet seating.
- Keep your work area clean and organized to prevent accidents.
- Do not use the Seater Head for purposes other than intended.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Carefully insert the Seater Head into the appropriate die.
- Tighten the die securely to prevent movement during use.
- Check alignment before proceeding with bullet seating.

2. Usage:

- Place a cartridge case in the reloading press.
- Insert the bullet into the case mouth.
- Slowly and steadily operate the press to seat the bullet.
- Monitor the process to ensure proper bullet alignment and seating depth.
- After use, remove the Seater Head and clean it to maintain performance.

Disposal Instructions

- Dispose of the Seater Head according to local regulations regarding metal waste.
- Do not dispose of the Seater Head in regular household waste.
- Consider recycling the product if possible.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for support

resources and additional information.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.