

Seater Head 9,30/.366-R66

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-R66
- Manufacturer: TRIEBEL
- Product no.: EU2017511
- Mfr. No.: 3000054V-09.30-R066
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R66
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R066

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366R66. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read through the entire guide before using the product to understand its features and safety precautions.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head in a wellventilated area to avoid inhalation of any particles.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Improper use may lead to malfunction or injury.
 - Ensure that the Seater Head is securely attached to the reloading press before use.
- **Avoiding Hazards:**
 - Do not exceed the recommended specifications for bullet seating.
 - Always wear safety glasses when using the Seater Head to protect your eyes from debris.
 - Use appropriate hearing protection if you are in a noisy environment.
- **Age Restrictions:**
 - This product is intended for use by individuals aged 18 and older. Ensure that younger individuals are supervised if they are present during use.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Attach the Seater Head to the reloading press according to the manufacturer's instructions.
- Verify that the Seater Head is securely fastened before proceeding.

2. Usage:

- Select the correct seater head using the tool on the manufacturer's website www.triebelreloading.com.
- Insert the bullet into the cartridge case and place it under the Seater Head.
- Slowly operate the reloading press to seat the bullet. Monitor the process to ensure proper alignment.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- If the product is damaged or no longer usable, consider recycling it where possible.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For safety inquiries or additional support, please refer to the manufacturer's website or customer service resources.

By following these safety instructions, you can ensure a safe and effective experience while using the Seater Head 9,30/.366R66. Always prioritize safety and compliance with local regulations.