

Seater Head 9,30/.366-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,30/.366-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017512
- Mfr. No.: 3000054V-09.30-R115
- Diameter (in): 0.366
- Diameter mm: 9,30
- Radius: R115
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.30-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,30/.366R115. This product is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure the safe use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is suitable for your specific reloading dies, particularly those from Triebel Waffenwerkzeuge.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

• Hazard Identification:

- The Seater Head is intended for precision bullet seating. Improper use may lead to inaccurate ammunition, which can be dangerous.
- Avoid using the product if it is damaged or if you are unsure of its compatibility with your reloading equipment.

• Instructions for Avoiding Hazards:

- Ensure that all equipment is properly set up and secured before use.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading components.
- Follow the recommended procedures for loading and unloading cartridges to prevent accidental discharge.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and free of debris.
- Select the correct Seater Head for your cartridge using the tool on the manufacturer's website.
- Securely attach the Seater Head to your reloading press according to the manufacturer's instructions.

2. Usage:

- Before starting, doublecheck that all components are correctly aligned and secured.
- Place the cartridge case in the press and ensure it is held firmly in place.
- Slowly and gently operate the press to seat the bullet. Avoid excessive force as this may damage the bullet or the Seater Head.
- After use, clean the Seater Head to maintain its precision and performance.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Recycle materials when possible. Follow your local guidelines for the disposal of brass and other components.

Contact Information for Further Support

For further assistance regarding safety inquiries or product support, please refer to the manufacturer's website or contact their support team directly.

Thank you for prioritizing safety in your reloading practices. Enjoy your experience with the Seater Head 9,30/.366R115 while adhering to these guidelines to ensure a safe and efficient process.