

Seater Head 9,50/.375-R51

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,50/.375-R51](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017517
- Mfr. No.: 3000054V-09.50-R051
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R51
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R051

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R51. This product is designed for precision bullet seating and is crafted from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that all users are aware of the safety guidelines associated with the use of this product.
- Always handle the Seater Head with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including safety glasses and gloves, when using reloading equipment.
- Ensure that the workspace is wellventilated and free from flammable materials.
- Do not exceed the recommended specifications for bullet seating to prevent accidents.
- Be cautious when handling bullets and other reloading components to avoid injury.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is securely mounted.
- Select the correct Seater Head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Carefully insert the Seater Head into the die, ensuring it is properly aligned.
- Tighten the Seater Head securely to prevent movement during use.

2. Usage

- Prepare your cartridges according to the reloading specifications.
- Insert the bullet into the case mouth and position it under the Seater Head.
- Activate the reloading press to seat the bullet gently. Monitor the process to ensure proper alignment.
- After completing the reloading process, inspect the cartridges for proper seating and alignment.

Disposal Instructions

- Dispose of any damaged or unusable components in accordance with local regulations.
- Do not dispose of the Seater Head or any metal components in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 9,50/.375R51. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk