

Seater Head 9,50/.375-R54

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R54
- Manufacturer: TRIEBEL
- Product no.: EU2017518
- Mfr. No.: 3000054V-09.50-R054
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R54
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R054

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 9,50/.375R54. This highquality brass product is precisionmachined for optimal performance in bullet seating. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always follow the manufacturer's instructions for use and installation.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before use.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates on the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seater Head only for its intended purpose, which is bullet seating.
- Avoid using excessive force during operation to prevent damage to the Seater Head and ensure safe usage.
- Always wear appropriate safety gear, such as safety glasses, when operating reloading equipment.
- Ensure that the working area is clean and free from obstructions to prevent accidents.
- Do not use the Seater Head if it shows any signs of damage or malfunction.
- Follow all local laws and regulations regarding ammunition reloading and safety.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Visit the manufacturer's website at www.trieb reloading.com to choose the appropriate Seater Head for your needs.

2. Installation:

- Ensure that your reloading press is turned off and disconnected from any power source before installation.
- Carefully remove the existing seater head from your reloading die.
- Install the Seater Head 9,50/.375R54 by following these steps:
 - Align the Seater Head with the die body.
 - Gently screw the Seater Head into place, ensuring it is secure but not overtightened.

3. Using the Seater Head:

- Prepare your cartridges and bullets according to standard reloading procedures.
- Insert the cartridge into the reloading press and position the bullet above the cartridge case.
- Activate the press to seat the bullet gently into the cartridge case, ensuring proper alignment.
- Check the alignment and seating depth after each operation to maintain accuracy.

4. PostUse Care:

- After using the Seater Head, clean it with a soft cloth to remove any debris or residue.
- Store the Seater Head in a safe, dry place away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Seater Head responsibly at a designated recycling facility or according to local regulations.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the appropriate support channels.

By following these guidelines, you can ensure safe and effective use of the Seater Head 9,50/.375R54. Thank you for your attention to safety.