

Seater Head 9,50/.375-R62

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R62
- Manufacturer: TRIEBEL
- Product no.: EU2017519
- Mfr. No.: 3000054V-09.50-R062
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R62
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R062

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R62. This guide provides essential safety instructions to ensure the safe use of this product. Please read this manual thoroughly before using the Seater Head, as it contains important information regarding safety, installation, and usage.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, such as eye protection, when using reloading equipment.
- Keep the work area clean and organized to prevent accidents.
- Store the Seater Head in a secure location, out of reach of children and pets.
- Regularly inspect the Seater Head for any signs of wear or damage before each use. If any issues are found, do not use the product and contact the manufacturer for guidance.
- Follow all local laws and regulations regarding ammunition reloading.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure that the Seater Head is properly secured in the reloading press before use.
- Avoid placing fingers or other body parts near the moving parts of the reloading press while in operation.
- Use the Seater Head only for its intended purpose, which is bullet seating.
- Be cautious when handling components that may be sharp or have the potential to cause injury.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials required for reloading.
- Ensure that your reloading press is clean and in good working condition.

2. Installation:

- Remove any existing seater head from the reloading press, if applicable.
- Carefully insert the Seater Head into the press, ensuring it is aligned correctly.
- Secure the Seater Head in place according to the manufacturer's instructions.

3. Usage:

- Begin the reloading process by following the specific guidelines for your chosen cartridge.
- Adjust the Seater Head as necessary to achieve the desired bullet seating depth.
- Monitor the process closely to ensure that the bullet is seated properly without any issues.
- After completing the seating process, carefully remove the finished cartridge from the press.

Disposal Instructions

- Dispose of any damaged or wornout components in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Instead, check with your local recycling or hazardous waste facility for proper disposal methods.

Contact Information for Further Support

For any inquiries related to safety, usage, or product support, please refer to the manufacturer's website. They provide resources and assistance for consumers.

By following these guidelines, you can help ensure a safe and effective reloading experience with the Seater Head 9,50/.375R62. Thank you for prioritizing safety in your reloading activities.