

## Seater Head 9,50/.375-R105

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: Seater Head 9,50/.375-R105
- Manufacturer: TRIEBEL
- Product no.: EU2017520
- Mfr. No.: 3000054V-09.50-R105
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R105
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R105

# Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 9,50/.375R105. This guide provides essential safety instructions to ensure the safe use of this product. Please read this guide carefully before using the Seater Head to maximize safety and performance.

## General Safety Guidelines

- Ensure that the Seater Head is used only in conjunction with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Inspect the Seater Head regularly for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding ammunition reloading and handling.

## Specific Safety Precautions for Use

- **Hazard Identification:** Improper use of the Seater Head can lead to misalignment of bullets, which may cause dangerous malfunctions during firing.
- **Avoiding Hazards:**
  - Always ensure that the Seater Head is securely attached to the reloading press before use.
  - Do not exceed the recommended specifications for bullet diameter and type.
  - Use the correct seater head for the specific bullet profile to ensure proper alignment.
  - Never attempt to modify or alter the Seater Head for any reason.
- **Age Specific Warning:** This product is not intended for use by individuals under the age of 18. Ensure that all users are of legal age and have proper training in reloading practices.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Clean the area where the Seater Head will be installed to remove any debris.
- Securely attach the Seater Head to the reloading press, following the manufacturer's instructions.
- Verify that the Seater Head is properly aligned before proceeding.

### 2. Usage:

- Prepare your cartridge cases and bullets according to the reloading guidelines.
- Insert the cartridge case into the reloading press and ensure it is seated correctly.
- Select the appropriate bullet for the Seater Head and place it on top of the cartridge case.
- Gradually lower the ram of the reloading press to seat the bullet. Monitor the process to ensure alignment.
- Once the bullet is seated, inspect the cartridge for proper seating and alignment before removing it from the press.

## Disposal Instructions

- Dispose of the Seater Head and any associated components in accordance with local regulations for metal recycling.
- Do not dispose of the Seater Head in regular household waste.

- Ensure that all components are properly cleaned and free of any hazardous materials before disposal.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact an authorized dealer.

By following these safety instructions, you will ensure a safe and effective reloading experience. Thank you for your attention to safety!