

Seater Head 9,50/.375-R108

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R108
- Manufacturer: TRIEBEL
- Product no.: EU2017521
- Mfr. No.: 3000054V-09.50-R108
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R108
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R108

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R108. This product is designed for precision bullet seating, ensuring optimal performance and accuracy in your reloading process. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to avoid injury or damage.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while reloading.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Ensure that the reloading equipment is stable and secure during use to prevent accidents.
- Avoid distractions while using the Seater Head to maintain focus and control.
- If you experience any malfunctions or irregularities during use, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Carefully remove the existing seater head from the die.
- Align the Seater Head 9,50/.375R108 with the die, ensuring proper fit.
- Securely tighten the Seater Head in place using the appropriate tools.
- Doublecheck that the installation is stable and secure before proceeding.

2. Usage:

- Set up your reloading press according to the manufacturer's instructions.
- Adjust the Seater Head to the desired depth for bullet seating.
- Insert the cartridge case into the press and ensure it is properly aligned with the Seater Head.
- Apply steady pressure to the press handle to seat the bullet gently.
- Inspect the completed cartridge for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local waste disposal regulations.
- Do not throw the Seater Head in regular household waste if it is made of materials that require special handling.
- Consider recycling options for metal components when disposing of the product.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's website or customer support resources. It is recommended to stay updated on product recalls and safety notices through the EU's Safety Gate platform.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 9,50/.375R108. Always prioritize safety and compliance with local regulations.