

Seater Head 9,50/.375-R130

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R130
- Manufacturer: TRIEBEL
- Product no.: EU2017523
- Mfr. No.: 3000054V-09.50-R130
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R130
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R130

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R130 by TRIEBEL. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read and follow these instructions carefully to avoid any hazards and ensure optimal performance.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head out of reach of children and unauthorized users.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling ammunition and reloading components.
- Familiarize yourself with the specific safety requirements for your reloading setup and environment.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use of the Seater Head can lead to cartridge malfunction or misfires.
- Inadequate alignment may result in inaccurate bullet seating, affecting overall accuracy.

- **Avoiding Hazards:**

- Always ensure that the Seater Head is properly attached to the reloading press before use.
- Do not exceed the recommended specifications for bullet and cartridge types as indicated by the manufacturer.
- Avoid using the Seater Head in wet or humid conditions, which can cause corrosion or malfunction.
- Store the Seater Head in a dry and secure location when not in use.

- **Audience Specific Warnings:**

- This product is not intended for use by individuals under the age of 18 without adult supervision.
- Ensure that inexperienced users are guided by a knowledgeable individual when using this product.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that the reloading press is turned off and unplugged.
2. Remove any existing seater heads from the press.
3. Carefully attach the Seater Head to the press, ensuring that it is securely fastened.
4. Align the Seater Head according to the manufacturer's specifications for optimal performance.

- **Usage:**

1. Prepare your cartridges and bullets according to the reloading guidelines.
2. Set the desired seating depth on the reloading press.
3. Insert the cartridge case into the press and position the bullet above the case.
4. Activate the press to seat the bullet gently into the cartridge case.

5. Inspect the completed cartridge for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations regarding metal waste.
- Do not throw the Seater Head in regular household waste.
- Check with local waste management authorities for proper disposal methods for reloading components.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Seater Head, please refer to the manufacturer's website or contact your local retailer.

Thank you for prioritizing safety while using the Seater Head 9,50/.375R130. Your adherence to these guidelines helps ensure a safe and enjoyable reloading experience.