

Seater Head 9,50/.375-R145

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 9,50/.375-R145](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017524
- Mfr. No.: 3000054V-09.50-R145
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R145
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R145

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R145. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the optimal performance of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before use.
- If you notice any defects, discontinue use immediately and consult the manufacturer.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Store the Seater Head in a dry, safe location to prevent damage and ensure longevity.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Improper use may lead to inaccurate bullet seating, which can affect firearm performance and safety.
 - Sharp edges may be present; handle with care to avoid cuts.
- **Avoiding Hazards:**
 - Always wear protective gloves when handling the Seater Head to avoid injury.
 - Ensure that your workspace is clean and free of obstructions before using the product.
 - Never exceed the recommended specifications provided by the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Carefully remove the existing seater head from your die.
- Align the Seater Head 9,50/.375R145 with the die and screw it in securely.
- Doublecheck that the Seater Head is properly seated and tightened to avoid any movement during use.

2. Usage:

- Prepare your cartridges according to the recommended specifications.
- Place the bullet into the cartridge case, ensuring proper alignment.
- Activate the reloading press slowly and steadily to seat the bullet.
- Monitor the seating depth to ensure consistency across all cartridges.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head responsibly if it becomes damaged beyond repair.
- Follow local regulations for the disposal of metal products.
- Do not throw the Seater Head in regular household waste; consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or support regarding the Seater Head, please refer to the manufacturer's website or contact the authorized distributor in your region.

By adhering to these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 9,50/.375R145. Thank you for your attention to safety and proper usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk