

Seater Head 9,50/.375-R190

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R190
- Manufacturer: TRIEBEL
- Product no.: EU2017525
- Mfr. No.: 3000054V-09.50-R190
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R190
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R190

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 9,50/.375R190. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the proper functioning of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that you are familiar with the operation of reloading equipment before using the Seater Head.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling ammunition components.
- Keep the Seater Head and all reloading equipment out of reach of children and unauthorized persons.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding reloading and ammunition handling.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Always doublecheck that the Seater Head is securely attached to the reloading press before use.
- Ensure that the bullet is properly aligned with the case before seating to prevent jams or misfires.
- Do not exceed the recommended load data for your specific reloading setup.
- If you notice any unusual noises or resistance during operation, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Remove the existing seater head from your reloading die if applicable.
- Clean the threads of the die and the new Seater Head to ensure a secure fit.
- Carefully screw the Seater Head into the reloading die until it is snug, but do not overtighten.
- Check that the Seater Head is properly aligned with the reloading press.

2. Usage:

- Prepare your cases and bullets according to standard reloading procedures.
- Place a case into the shell holder of the reloading press.
- Insert a bullet into the case mouth, ensuring it is properly seated.
- Operate the reloading press to seat the bullet using the Seater Head. Monitor the process for any irregularities.
- After use, clean the Seater Head and store it in a safe, dry place.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not dispose of reloading components in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any questions regarding the use or safety of the Seater Head, please consult the manufacturer's website at

www.triebelreloading.com for further assistance and information.