

Seater Head 9,50/.375-R200

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 9,50/.375-R200
- Manufacturer: TRIEBEL
- Product no.: EU2017526
- Mfr. No.: 3000054V-09.50-R200
- Diameter (in): 0.375
- Diameter mm: 9,50
- Radius: R200
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-09.50-R200

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Seater Head 9,50/.375R200](#)

Safety Instruction Guide for Seater Head 9,50/.375R200

Introduction

Thank you for choosing the Seater Head 9,50/.375R200. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- **Product Safety:** This product is designed to ensure safe use. Always follow the instructions and guidelines provided.
- **Enhanced Recalls:** In the event of a product recall, standardized notices will be issued, and remedies will be provided free of charge for any dangerous products.
- **Online Shopping:** The same safety protections apply when purchasing online as they do in physical stores. Ensure that the online platform complies with safety requirements.
- **Special Consumer Focus:** Extra safeguards are in place for vulnerable groups, such as children. Keep this product out of reach of children.
- **EU Contact Point:** For any safety inquiries, please refer to the contact point provided by the manufacturer.
- **Rapid Alerts:** Stay informed about unsafe products through the EU's Safety Gate system.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper handling may lead to personal injury.
 - Misalignment during use can affect cartridge accuracy and safety.
- **Avoiding Hazards:**
 - Always inspect the seater head before use for any signs of damage or wear.
 - Ensure that you are using the correct seater head for your specific die and cartridge.
 - Use protective eyewear to safeguard against potential debris during operation.
- **AudienceSpecific Warnings:**
 - This product is intended for use by adults. Do not allow minors to operate or handle this product.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading press is turned off and unplugged before installation.
 2. Remove any existing seater head from the die.
 3. Carefully install the Seater Head 9,50/.375R200 into the die, ensuring it is securely fastened.
 4. Verify that the seater head is properly aligned and locked in place before use.
- **Usage:**
 1. Prepare your cartridge case and bullet according to standard reloading practices.
 2. Insert the cartridge case into the reloading press.
 3. Position the bullet on top of the cartridge case.
 4. Slowly operate the press to seat the bullet. Monitor the alignment to ensure proper seating.
 5. After use, clean the seater head to remove any residue and ensure longevity.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal waste.
- Do not dispose of the product in regular household waste. Check for designated recycling centers in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 9,50/.375R200, please refer to the manufacturer's website or customer service resources for assistance.

By following these guidelines, you can ensure safe and effective use of your Seater Head. Thank you for your attention to safety and for choosing our product.