

Seater Head 10,30/.413-R55

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,30/.413-R55
- Manufacturer: TRIEBEL
- Product no.: EU2017529
- Mfr. No.: 3000054V-10.30-R055
- Diameter (in): 0.413
- Diameter mm: 10,30
- Radius: R55
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.30-R055

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,30/.413R55 by TRIEBEL. This product is designed for precision bullet seating in rifle reloading. To ensure safe use and optimal performance, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always handle the Seater Head with care to prevent injury.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage.
- Follow all local regulations regarding the use and storage of reloading equipment.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Before using the Seater Head, ensure that your reloading equipment is compatible.
- Always wear appropriate safety gear, including safety glasses and gloves, while reloading.
- Ensure that the work area is wellventilated and free from flammable materials.
- Do not exceed the recommended specifications for bullet seating as indicated by the manufacturer.
- In case of any malfunction or unusual behavior during use, stop immediately and inspect the equipment.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for reloading.
- Ensure that your reloading press is securely mounted and stable.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Inspect the Seater Head for any visible damage.
- Install the Seater Head onto your reloading press according to the manufacturer's instructions.
- Ensure that the Seater Head is securely tightened to prevent movement during use.

3. Usage:

- Set the desired bullet seating depth according to your reloading specifications.
- Place the cartridge case into the reloading press and ensure it is properly aligned.
- Insert the bullet into the case mouth and engage the Seater Head.
- Slowly operate the reloading press to seat the bullet gently.
- After seating, check the cartridge for proper alignment and depth.

4. PostUse:

- After completing your reloading session, clean the Seater Head and surrounding area.
- Store the Seater Head in a safe and dry location, away from children and pets.

Disposal Instructions

- Dispose of any packaging materials in accordance with local recycling regulations.
- If the Seater Head becomes damaged beyond repair, dispose of it responsibly, ensuring it does not pose a hazard to others.
- Check local regulations for specific disposal instructions related to reloading equipment.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or customer support resources. Always ensure you have the latest safety updates and product recalls by checking the EU's Safety Gate platform.

Thank you for prioritizing safety while using your Seater Head. Enjoy your reloading experience!