

Seater Head 10,30/.413-R65

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,30/.413-R65
- Manufacturer: TRIEBEL
- Product no.: EU2017530
- Mfr. No.: 3000054V-10.30-R065
- Diameter (in): 0.413
- Diameter mm: 10,30
- Radius: R65
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.30-R065

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,30/.413R65. This guide provides important safety instructions and guidelines to ensure the safe and effective use of this product. Please read this document carefully before use.

General Safety Guidelines

- Ensure safe use of the Seater Head by following all instructions provided in this guide.
- Be aware of potential hazards associated with the use of reloading tools.
- Regularly check for updates and recalls on the EU's Safety Gate platform.
- Keep this guide accessible for future reference.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when using reloading tools.
- Keep the workspace clean and organized to avoid accidents.
- Ensure that the Seater Head is compatible with your reloading dies and equipment.
- Do not modify the Seater Head or any associated equipment, as this may lead to safety hazards.
- Store the Seater Head in a safe place, out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before each use. Do not use if damaged.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head

- Use the tool on the manufacturer's website (www.tribelreloading.com) to select the correct seater head for your needs.

2. Installation

- Ensure that your reloading die is securely mounted in your reloading press.
- Carefully insert the Seater Head into the die, ensuring a snug fit.
- Tighten any locking mechanisms to secure the Seater Head in place.

3. Usage

- Follow the manufacturer's instructions for loading and seating bullets.
- Use consistent pressure and speed when operating the reloading press to ensure uniform bullet seating.
- Monitor the alignment of the cartridge during the seating process to maintain accuracy.
- If you encounter any resistance while seating, stop and inspect the setup before proceeding.

4. PostUse Care

- After use, clean the Seater Head and surrounding area to remove any debris or residue.
- Store the Seater Head in its protective case or designated storage area.

Disposal Instructions

- Dispose of any damaged or wornout components in accordance with local regulations.
- Do not throw the Seater Head or its components in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for contact information and additional support resources.

By following these safety instructions, you can help ensure a safe and effective reloading experience. Thank you for your attention to these guidelines.