

Seater Head 10,30/.413-R95

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,30/.413-R95
- Manufacturer: TRIEBEL
- Product no.: EU2017531
- Mfr. No.: 3000054V-10.30-R095
- Diameter (in): 0.413
- Diameter mm: 10,30
- Radius: R95
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.30-R095

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,30/.413R95. This product is designed for precise and gentle bullet seating, enhancing your reloading experience. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the work area is clean and free from obstructions before starting.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, to protect yourself during the reloading process.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Potential risks include improper bullet seating, which may lead to cartridge malfunction.
- Avoid contact with sharp edges or moving parts during operation.

- **Instructions for Avoiding Hazards:**

- Always ensure that the Seater Head is securely attached to the reloading die before use.
- Follow the manufacturer's guidelines for bullet seating depth and pressure.
- Do not exceed the recommended specifications for bullet diameter and weight.

- **Audience Specific Warnings:**

- This product is intended for use by individuals with a basic understanding of reloading practices.
- It is not suitable for use by children or individuals without proper training.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading die is clean and free of debris.
- Carefully attach the Seater Head to the reloading die, ensuring it is securely fastened.
- Check the alignment of the Seater Head with the die body to ensure proper function.

2. Usage:

- Select the correct seater head using the tool on the manufacturer's website www.triebelreloading.com.
- Load the bullet into the case and position it under the Seater Head.
- Gradually apply pressure to the reloading press to seat the bullet. Monitor the process closely to ensure proper seating depth.
- After use, clean the Seater Head to maintain its precision and longevity.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of the Seater Head or any reloading components in household waste.
- Check with local waste management authorities for proper disposal methods for metallic and hazardous materials.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please consult the manufacturer's website or customer support resources.

By following these guidelines, you can ensure the safe and effective use of your Seater Head 10,30/.413R95. Thank you for prioritizing safety in your reloading practices.