

Seater Head 10,36/.408-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,36/.408-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017532
- Mfr. No.: 3000054V-10.36-R115
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R115
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,36/.408R115. This product is designed for precise and gentle bullet seating, enhancing the accuracy of your reloading process. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Do not use the product for any purpose other than its intended use.
- Store the product in a dry and secure place when not in use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that you are using the correct seater head for your specific reloading die.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Avoid working in cluttered or poorly lit areas to minimize the risk of accidents.
- Ensure that all components of your reloading setup are compatible and securely attached before use.
- Do not exceed the recommended bullet seating depth or pressure limits specified by the manufacturer.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to select the appropriate seater head for your reloading needs.

2. Installation:

- Ensure that your reloading die is clean and free from debris.
- Carefully insert the seater head into the die until it is securely in place.
- Tighten the locking mechanism according to the manufacturer's specifications to ensure stability during use.

3. Usage:

- Set your reloading press to the appropriate settings as per your reloading data.
- Place the cartridge case in the shell holder and ensure it is seated correctly.
- Insert the bullet into the case mouth.
- Slowly operate the press to seat the bullet, ensuring that the bullet is aligned properly.
- After seating, check the overall cartridge length and bullet seating depth for accuracy.

Disposal Instructions

- Dispose of any damaged or wornout components in accordance with local regulations.
- Do not dispose of the product in regular household waste. Consult your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website for contact details and support resources.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head 10,36/.408R115. Thank you for prioritizing safety in your reloading practices.