

Seater Head 10,36/.408-R120

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,36/.408-R120](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017533
- Mfr. No.: 3000054V-10.36-R120
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R120
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R120

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,36/.408R120. This product is designed to enhance your reloading experience and improve the precision of your ammunition. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that you understand the operation of the Seater Head before use.
- Always handle the Seater Head with care to avoid injury.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head only with compatible equipment as specified by the manufacturer.
- Regularly inspect the Seater Head for any signs of damage or wear.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when using the Seater Head.
- Ensure that the work area is clean and free from obstructions to prevent accidents.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using the Seater Head if you are unfamiliar with reloading procedures or if you feel fatigued.
- Follow the manufacturer's guidelines for compatible dies and equipment to prevent malfunction.

Instructions for Installation and Usage

1. Installation:

- Ensure your workspace is clean and organized.
- Select the correct seater head using the tool on the manufacturer's website: www.triebelreloading.com.
- Carefully attach the Seater Head to the reloading press, following the manufacturer's instructions for your specific equipment.
- Verify that the Seater Head is securely fastened before use.

2. Usage:

- Adjust the Seater Head to the desired bullet seating depth as per your reloading specifications.
- Place the cartridge case in the reloading press and align it with the Seater Head.
- Slowly and steadily operate the press to seat the bullet. Avoid applying excessive force.
- Inspect each cartridge for proper bullet seating and alignment before proceeding to the next one.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of the Seater Head in regular household waste.
- Consider recycling options available in your area for brass materials.

Contact Information for Further Support

For further assistance or inquiries regarding safety or product information, please refer to the manufacturer's website or contact their customer support.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head

10,36/.408R120. Always prioritize safety and consult the manufacturer for any specific concerns.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk