

Seater Head 10,36/.408-R135

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,36/.408-R135](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017534
- Mfr. No.: 3000054V-10.36-R135
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R135
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R135

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head 10,36/.408R135](#)
- [About Us](#)

Safety Instruction Guide for Seater Head 10,36/.408R135

Introduction

Thank you for choosing the Seater Head 10,36/.408R135. This product is designed for precision bullet seating in your reloading process. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is suitable for your specific reloading setup and compatible with your reloading dies.
- Keep the Seater Head out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Risk of injury from improper handling or misuse.
- Risk of inaccurate bullet seating leading to potential firearm malfunction.

- **Avoiding Hazards:**

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading equipment.
- Ensure that your workspace is clean and welllit to prevent accidents.
- Do not force the Seater Head into the die; ensure proper alignment before use.
- Avoid using the Seater Head with incompatible or damaged dies.
- Keep hands and other body parts clear of moving parts during operation.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Remove any existing seater head from your die.
- Carefully install the Seater Head 10,36/.408R135 into the die, ensuring it is properly aligned.
- Tighten the seater head securely according to the manufacturer's specifications.

2. Usage:

- Prepare your cartridges according to standard reloading practices.
- Insert a bullet into the cartridge case and place it in the die.
- Operate your reloading press smoothly and evenly to seat the bullet.
- Check for proper bullet seating depth after each round.
- If you notice any irregularities, stop using the Seater Head immediately and inspect for issues.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of in regular household waste if it is damaged or no longer usable.
- Consider recycling options for brass materials where available.

Contact Information for Further Support

For any inquiries regarding the safety and use of the Seater Head 10,36/.408R135, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for your attention to these safety instructions. Your safety and the effective use of the Seater Head are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk