

Seater Head 10,36/.408-R160

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,36/.408-R160](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017535
- Mfr. No.: 3000054V-10.36-R160
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R160
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R160

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,36/.408R160. This guide provides essential safety instructions to ensure the safe and effective use of this product. It is designed to help you understand the proper handling, installation, and disposal of the Seater Head while complying with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the product instructions before use.
- Ensure that the Seater Head is used only with compatible equipment, specifically original dies from Triebel Waffenwerkzeuge.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Ensure that your workspace is clean and free from obstructions to prevent accidents.
- Avoid using the Seater Head if you are tired or under the influence of substances that may impair your judgment.
- Do not attempt to modify or repair the Seater Head yourself; consult a professional if repairs are needed.
- Follow all local regulations regarding the use and handling of reloading equipment.

Instructions for Installation and Usage

1. Preparation:

- Ensure your work area is welllit and organized.
- Gather all necessary tools and materials before starting.

2. Installation:

- Carefully attach the Seater Head to the compatible die, ensuring a secure fit.
- Check that all components are correctly aligned and tightened to prevent any movement during operation.

3. Usage:

- Load the cartridge according to the manufacturer's specifications.
- Operate the reloading press smoothly, applying consistent pressure to ensure proper bullet seating.
- Monitor the process closely to detect any irregularities or issues early.

4. PostUsage:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a safe and dry location, away from children and pets.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local waste disposal regulations.
- Do not dispose of the product in household waste if it contains hazardous materials.
- Consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or further support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor.

By following these safety instructions, you can help ensure a safe and effective experience with the Seater Head 10,36/.408R160. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk