

Seater Head 10,36/.408-R235

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,36/.408-R235
- Manufacturer: TRIEBEL
- Product no.: EU2017537
- Mfr. No.: 3000054V-10.36-R235
- Diameter (in): 0.408
- Diameter mm: 10,36
- Radius: R235
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.36-R235

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 10,36/.408R235. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always read the manufacturer's instructions and guidelines before use.
- Keep the product out of reach of children and unauthorized users.
- Inspect the Seater Head for any damage before use. Do not use if damaged.
- Store the Seater Head in a cool, dry place to prevent corrosion and damage.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Ensure that the work area is clean and free from obstructions.
- Avoid direct contact with the Seater Head during operation to prevent injury.
- Do not exceed the recommended specifications for the Seater Head, including pressure limits and compatibility.
- Be cautious of potential sharp edges on the Seater Head during handling.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your reloading press is properly set up and secured.
- Gather all necessary tools and materials for reloading.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Align the Seater Head with the die according to the manufacturer's instructions.
- Tighten the Seater Head securely to prevent any movement during use.

3. Usage:

- Place the cartridge case in the reloading press.
- Insert the bullet into the cartridge case.
- Activate the press to seat the bullet using the Seater Head.
- Monitor the seating depth and adjust as necessary for accuracy.

4. PostUse:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in its original packaging or a designated storage container.

Disposal Instructions

- Dispose of any packaging materials according to local regulations.

- If the Seater Head is no longer usable, follow local guidelines for the disposal of metal products.
- Do not throw the Seater Head in regular household waste if it is still functional; consider recycling options.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's website or contact their customer service directly. It is important to stay informed about any product recalls or safety alerts by checking the EU's Safety Gate platform regularly.

By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 10,36/.408R235. Thank you for prioritizing safety in your reloading activities.