

Seater Head 10,57/.416-K15

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,57/.416-K15
- Manufacturer: TRIEBEL
- Product no.: EU2017538
- Mfr. No.: 3000054V-10.57-K15
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: K15
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-K15

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416K15. This product is designed for precise and gentle bullet seating, ensuring optimal axial bullet alignment and improved cartridge concentricity. To ensure your safety and the effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to prevent personal injury and damage to the product.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.
- Ensure that the work area is clean, dry, and welllit to avoid accidents.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- If you experience any unusual behavior or performance from the Seater Head, discontinue use immediately and consult a professional.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Select the correct Seater Head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Carefully attach the Seater Head to the reloading die, ensuring a secure fit.
- Doublecheck that the Seater Head is properly aligned before proceeding.

2. Usage:

- Load the cartridge case into the reloading press and position the bullet above the case mouth.
- Activate the press to seat the bullet gently into the case.
- Monitor the process closely to ensure that the bullet is seated correctly.
- After use, clean the Seater Head with a soft cloth to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or no longer usable.
- Consider recycling the Seater Head if possible, as it is made from highquality brass.

Contact Information for Further Support

For further support or inquiries regarding safety or performance issues, please refer to the manufacturer's website or contact the appropriate authority in your region.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 10,57/.416K15. Always prioritize safety and remain informed about the best practices for using reloading equipment. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.