

Seater Head 10,57/.416-R20

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-R20](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017540
- Mfr. No.: 3000054V-10.57-R020
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R20
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R020

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R20. This guide provides important safety instructions and information to ensure the safe use of this product. Please read this guide carefully before using the Seater Head to understand how to operate it safely and effectively.

General Safety Guidelines

- Ensure that you are familiar with the product and its intended use before handling it.
- Always follow the manufacturer's instructions and guidelines for safe use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including eye protection, when using this product.
- Avoid using the Seater Head if you are tired or under the influence of substances that may impair your judgment.
- Ensure that the work area is clean and free of obstructions to prevent accidents.
- Do not exceed the recommended specifications for diameter and radius when using the Seater Head.

Instructions for Installation and Usage

1. Installation:

- Select the correct Seater Head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Ensure that the Seater Head is securely attached to the die before use.
- Verify that the setup is properly aligned to ensure optimal performance.

2. Usage:

- Place the cartridge case into the die and ensure it is properly seated.
- Gently lower the press handle to seat the bullet. Do not apply excessive force.
- Monitor the alignment of the bullet during the seating process to maintain cartridge concentricity.
- After use, clean the Seater Head to remove any residues or debris.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of the Seater Head in regular household waste.
- If the product is damaged or no longer usable, consider recycling the brass material if possible.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact their customer support for assistance.

By following these safety instructions and guidelines, you can ensure a safe and effective experience while

using the Seater Head 10,57/.416R20. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk