

Seater Head 10,57/.416-R30

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-R30](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017541
- Mfr. No.: 3000054V-10.57-R030
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R30
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R030

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R30. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure safe and effective use, please read and adhere to the following safety instructions and guidelines.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding the use of reloading equipment and ammunition.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Use the Seater Head only for its intended purpose of bullet seating.
- Do not exceed the recommended specifications for diameter and radius as indicated in the product details.
- Ensure that the work area is clean and free from obstructions when using the Seater Head.
- Avoid using excessive force when seating bullets to prevent injury or damage to the Seater Head.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and properly set up.
- Carefully install the Seater Head into the appropriate die, ensuring it is securely fastened.
- Verify that the Seater Head is properly aligned with the reloading press.

2. Usage:

- Prepare your cartridge case and bullet according to standard reloading practices.
- Place the bullet into the case mouth, ensuring it is properly positioned.
- Operate the reloading press to gently seat the bullet using the Seater Head.
- Monitor the seating depth and alignment during the process to ensure optimal performance.

Disposal Instructions

- Dispose of any damaged or worn Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website for further assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk