

Seater Head 10,57/.416-R42

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,57/.416-R42
- Manufacturer: TRIEBEL
- Product no.: EU2017542
- Mfr. No.: 3000054V-10.57-R042
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R42
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R042

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R42. This product is designed to enhance your reloading experience with precision and safety in mind. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure the Seater Head is used only for its intended purpose.
- Always follow the manufacturer's instructions when using this product.
- Keep the Seater Head and all reloading equipment out of reach of children.
- Inspect the Seater Head for any damage before use. Do not use if damaged.
- Use appropriate personal protective equipment (PPE) such as safety glasses when reloading.
- Be aware of your surroundings and ensure a safe working environment when using this product.

Specific Safety Precautions for Use

- Only use the Seater Head with original dies from Triebel Waffenwerkzeuge.
- Verify compatibility with your reloading equipment before use.
- Avoid excessive force when seating bullets to prevent injury or equipment damage.
- Do not modify the Seater Head or use it for purposes other than intended.
- Store the Seater Head in a dry, cool place to prevent corrosion or damage.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for reloading.
- Ensure that your workspace is clean and organized.

2. Installation:

- Securely attach the Seater Head to the reloading die following the manufacturer's instructions.
- Ensure that the Seater Head is properly aligned to avoid misalignment during use.

3. Usage:

- Place a cartridge case in the reloading press and ensure it is secure.
- Insert the bullet into the case mouth, aligning it with the Seater Head.
- Gradually apply pressure to the reloading press to seat the bullet. Monitor the process closely to ensure proper seating.
- After use, remove the Seater Head and clean it to maintain its precision and functionality.

Disposal Instructions

- Dispose of any damaged or worn components of the Seater Head according to local regulations.
- Do not dispose of the Seater Head in regular household waste. Follow your local guidelines for hazardous materials if applicable.

Contact Information for Further Support

For any safety inquiries or support related to the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com.

By following this safety instruction guide, you contribute to a safer reloading process and ensure the longevity and effectiveness of your Seater Head. Thank you for prioritizing safety in your reloading activities.