

Seater Head 10,57/.416-R75

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,57/.416-R75
- Manufacturer: TRIEBEL
- Product no.: EU2017543
- Mfr. No.: 3000054V-10.57-R075
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R75
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R075

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R75. This guide provides essential safety instructions and user information to ensure the safe and effective use of this product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose to avoid accidents.
- Follow all instructions and safety guidelines provided in this document.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Avoid direct contact with sharp edges or moving parts during operation.
- Ensure that the workspace is clean and free from clutter to prevent accidents.
- Do not modify the Seater Head or use it in a manner not recommended by the manufacturer.
- If you experience any difficulties during use, stop immediately and consult the manufacturer's guidelines.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is compatible with the Seater Head.
- Remove any existing seater heads from your reloading dies.
- Carefully install the Seater Head into the die by following these steps:
 - Align the threads of the Seater Head with the die.
 - Gently screw the Seater Head into the die until it is securely in place.
 - Do not overtighten, as this may cause damage.

2. Usage:

- Before starting, ensure that all components of your reloading setup are clean and free from debris.
- Set the desired bullet seating depth according to your load specifications.
- Insert the cartridge case into the reloading press and ensure it is properly aligned.
- Gradually lower the press handle to seat the bullet. Monitor the process closely for any irregularities.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head responsibly. If the product is damaged or no longer usable, follow local regulations for hazardous waste disposal.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or product use, please refer to the manufacturer's website for guidance and support.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the Seater Head 10,57/.416R75. Always prioritize safety and consult the manufacturer's resources for any additional information. Thank you for your attention to these important guidelines.