

Seater Head 10,57/.416-R160

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-R160](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017546
- Mfr. No.: 3000054V-10.57-R160
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R160
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R160

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10.57/.416R160 from TRIEBEL. This product is designed for precision bullet seating and ensures optimal performance when used correctly. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle the Seater Head with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Use the Seater Head only for its intended purpose as specified in this guide.
- Regularly check for signs of wear or damage before each use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading dies before use.
- Always wear appropriate safety gear, such as safety glasses and gloves, when using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Avoid using the Seater Head in wet or damp conditions to prevent slips and accidents.
- Do not modify the Seater Head in any way, as this may compromise safety and effectiveness.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Visit the manufacturer's website at www.tribelreloading.com to select the appropriate seater head for your needs.

2. Installation:

- Ensure the reloading press is securely mounted and stable.
- Insert the Seater Head into the reloading die according to the manufacturer's instructions.
- Tighten the Seater Head securely to prevent it from loosening during use.

3. Usage:

- Follow the specific reloading instructions provided with your reloading kit.
- Place the cartridge case in the reloading press and ensure it is properly aligned with the Seater Head.
- Operate the reloading press smoothly and steadily to ensure proper bullet seating.
- Regularly check the alignment and seating depth for accuracy.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not throw the Seater Head in regular waste if it is damaged or broken.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the safety or usage of the Seater Head, please refer to the manufacturer's website for support and resources.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk