

Seater Head 10,57/.416-R235

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-R235](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017547
- Mfr. No.: 3000054V-10.57-R235
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R235
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R235

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R235. This product is designed for precision bullet seating in reloading applications. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that you are familiar with the safe use of reloading equipment before using the Seater Head.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling materials.
- Keep the workspace clean and free from obstructions to prevent accidents.
- Store the Seater Head in a secure location, out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding ammunition reloading.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Confirm that the diameter and radius specifications match your reloading setup:
 - Diameter (in): 0.416
 - Diameter V mm: 10.57
 - Radius V: R235
- Avoid applying excessive force during bullet seating to prevent damage to the Seater Head and ensure consistent performance.
- Do not modify the Seater Head in any way, as this may compromise safety and performance.
- If you experience any issues during use, stop and consult the manufacturer's guidelines or seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is powered off and disconnected from any power source.
- Carefully remove the existing seater head from the die.
- Insert the Seater Head 10,57/.416R235 into the die, ensuring it is securely seated.
- Tighten the locking mechanism to hold the Seater Head in place.

2. Usage:

- Adjust the die according to your specific reloading requirements.
- Place the cartridge case in the reloading press and align it with the Seater Head.
- Slowly and steadily press the handle to seat the bullet into the cartridge case.
- Check the alignment and seating depth after each operation to ensure accuracy.
- Once reloading is complete, clean the Seater Head and store it properly.

Disposal Instructions

- Dispose of any damaged or wornout components of the Seater Head responsibly.
- Follow local regulations for the disposal of metal and reloading materials.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for additional resources and support.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk