

Seater Head 10,75/.423-R30

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 10,75/.423-R30
- Manufacturer: TRIEBEL
- Product no.: EU2017549
- Mfr. No.: 3000054V-10.75-R030
- Diameter (in): 0.435
- Diameter mm: 10,75
- Radius: R30
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.75-R030

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 10,75/.423R30. This product has been designed to provide precision and accuracy in bullet seating. To ensure safe and effective use, please read this safety instruction guide carefully. It will provide you with essential information regarding the safe use, installation, and disposal of the product.

General Safety Guidelines

- Always use the seater head in accordance with the manufacturer's instructions.
- Ensure that the seater head is compatible with the dies you are using.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the seater head for any signs of wear or damage.
- If you notice any defects, discontinue use immediately and contact the manufacturer.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the seater head only with appropriate reloading equipment.
- Ensure that the workspace is clean, welllit, and free of distractions.
- Always wear safety glasses to protect your eyes during reloading operations.
- Avoid wearing loose clothing or accessories that may get caught in machinery.
- Do not exceed the recommended load specifications when using the seater head.
- Handle all components with care to avoid injury or damage.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting.
- Ensure that the reloading press is securely mounted and stable.

2. Installation:

- Remove any previous seater heads from the reloading die.
- Carefully screw the Seater Head 10,75/.423R30 into the die until snug.
- Ensure that the seater head is aligned properly for optimal performance.

3. Usage:

- Select the correct seater head using the tool on the manufacturer's website at www.triebelreloading.com.
- Place the cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Activate the reloading press to seat the bullet gently.
- Check the cartridge for proper bullet seating depth and alignment.

4. PostUsage:

- Clean the seater head and surrounding area after use.
- Store the seater head in a safe and dry location.

Disposal Instructions

- Dispose of any damaged or unusable components in accordance with local waste disposal regulations.
- Do not throw the seater head or any associated components in regular household trash.
- Consider recycling options for metal components if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 10,75/.423R30, please refer to the manufacturer's website for support resources and contact information.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head. Thank you for your attention to safety.