

Seater Head 11,05/.435-R5

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,05/.435-R5
- Manufacturer: TRIEBEL
- Product no.: EU2017550
- Mfr. No.: 3000054V-11.05-R005
- Diameter (in): 0.435
- Diameter mm: 11,05
- Radius: R5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.05-R005

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 11,05/.435R5, a precision tool designed for bullet seating. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the safety instructions before using the product.
- Ensure that the product is suitable for your specific reloading needs.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you notice any defects or irregularities, discontinue use immediately and contact the manufacturer.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling ammunition components.
- Avoid using excessive force during bullet seating; this can lead to misalignment or damage.
- Do not exceed the recommended specifications for bullet and cartridge dimensions.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Carefully attach the Seater Head to the press according to the manufacturer's instructions.
- Verify that the Seater Head is tightened securely and is properly aligned.

2. Usage:

- Select the appropriate bullet and cartridge combination for your reloading needs.
- Place the cartridge case in the press and ensure it is properly seated.
- Gently lower the Seater Head onto the bullet, applying even pressure.
- Monitor the seating process to ensure that the bullet is aligned correctly.
- After seating, inspect the cartridge for proper bullet alignment and depth.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options for metal components when available.

Contact Information for Further Support

For any safety inquiries or support regarding the Seater Head 11,05/.435R5, please refer to the manufacturer's website or contact their customer service.

Thank you for prioritizing safety while using the Seater Head. By following these guidelines, you can ensure a safe and successful reloading experience.