

Seater Head 11,20/.441-R37

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,20/.441-R37
- Manufacturer: TRIEBEL
- Product no.: EU2017552
- Mfr. No.: 3000054V-11.20-R037
- Diameter (in): 0.441
- Diameter mm: 11,20
- Radius: R37
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.20-R037

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 11,20/.441R37. This product is designed for precision bullet seating and is manufactured from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully. It contains important information regarding the safe operation, installation, and disposal of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle the Seater Head with care.
- Ensure the work area is clean and free from distractions.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling and using this product.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear. Do not use if damaged.
- Store the product in a dry, cool place to prevent corrosion.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading equipment. Refer to the manufacturer's specifications.
- Do not exceed the recommended diameter and radius specifications when using the Seater Head.
- Avoid using excessive force during bullet seating to prevent damage to the bullet and Seater Head.
- Always check for proper alignment before seating bullets to ensure cartridge concentricity.
- Follow the manufacturer's instructions for the use of dies and reloading equipment.
- If you experience any issues while using the product, cease operation immediately and consult a qualified technician.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and properly set up.
- Carefully screw the Seater Head into the die body until it is securely fastened.
- Adjust the Seater Head according to the specifications provided by the manufacturer for optimal performance.

2. Usage:

- Prepare your cartridges according to standard reloading practices.
- Place a bullet into the case mouth.
- Align the cartridge with the Seater Head in the die.
- Slowly and steadily apply pressure to the reloading press handle to seat the bullet.
- Inspect the seated bullet for proper depth and alignment.
- Repeat the process for additional cartridges, ensuring consistent and careful operation.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for recycling programs that accept metal materials.
- If the product is damaged beyond repair, consider contacting a recycling facility that specializes in metal.

recycling.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact their customer support for assistance. They will provide you with the necessary information related to safety, maintenance, and product support.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities.