

Seater Head 11,60/.458-R37

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,60/.458-R37
- Manufacturer: TRIEBEL
- Product no.: EU2017555
- Mfr. No.: 3000054V-11.60-R037
- Diameter (in): 0.458
- Diameter mm: 11,60
- Radius: R37
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.60-R037

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 11,60/.458R37. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this document carefully before using the seater head to understand the risks and best practices associated with its use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose, which is bullet seating for reloading cartridges.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the seater head out of reach of children and vulnerable individuals.
- Regularly inspect the seater head for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the handling and use of reloading equipment.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for bullet seating as indicated by the manufacturer.
- Ensure that the seater head is properly secured to the reloading press before use.
- Avoid using the seater head with damaged or incompatible dies.
- Do not attempt to modify the seater head or use it for purposes other than those specified by the manufacturer.
- If you experience any unusual resistance or difficulty during bullet seating, stop using the product immediately and inspect it for any issues.

Instructions for Installation and Usage

1. Installation:

- Remove any existing seater head from the reloading press.
- Clean the threads of the press to ensure a secure fit.
- Carefully screw the Seater Head 11,60/.458R37 onto the press until it is snug, but do not overtighten.
- Verify that the seater head is aligned correctly and is functioning smoothly.

2. Usage:

- Select the correct bullet and cartridge combination as per your reloading specifications.
- Place the cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring it is aligned with the seater head.
- Slowly operate the reloading press to seat the bullet. Maintain steady pressure without forcing the operation.
- After use, clean the seater head and store it in a safe, dry place.

Disposal Instructions

- Dispose of the seater head responsibly when it is no longer usable.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the product in regular household waste if it is deemed hazardous.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head 11,60/.458R37, please refer to the manufacturer's website or contact the relevant authorities in your country. Always ensure you have the latest information on product recalls or safety notices.

By following these guidelines, you can ensure a safer experience while using the Seater Head 11,60/.458R37. Always prioritize safety and take the necessary precautions when handling reloading equipment. Thank you for your attention to these important safety instructions.