

# Seater Head 11,60/.458-R120

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



## Attributes

- Name: [Seater Head 11,60/.458-R120](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017557
- Mfr. No.: 3000054V-11.60-R120
- Diameter (in): 0.458
- Diameter mm: 11,60
- Radius: R120
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.60-R120

# Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 11,60/.458R120. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read all sections carefully before using the product.

## General Safety Guidelines

- Always follow the manufacturer's instructions for safe usage.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any signs of damage or wear before each use.
- Use the product only for its intended purpose.
- Report any unsafe products or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- **Hazard Identification:** Improper use may lead to misalignment of bullets, affecting accuracy and safety. Ensure that the Seater Head is securely attached to the reloading die before use.
- **Avoiding Hazards:** Always wear safety glasses when reloading to protect your eyes from debris. Do not exceed the recommended specifications for bullet seating. Handle all reloaded ammunition with care, ensuring it is stored safely.
- **Age Specific Warnings:** This product is not intended for use by individuals under the age of 18 without adult supervision.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing seater head from the die if applicable.
- Carefully attach the Seater Head 11,60/.458R120 to the reloading die, ensuring a secure fit.
- Check for proper alignment and functionality before proceeding.

### 2. Usage:

- Adjust the seating depth according to your specifications.
- Place a cartridge case into the reloading press.
- Insert the bullet into the case mouth, ensuring it is aligned with the Seater Head.
- Activate the reloading press to seat the bullet gently. Monitor the process to ensure proper seating.
- After use, clean the Seater Head to maintain its performance and longevity.

## Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal waste.
- Do not dispose of the product in regular household waste. Check for recycling options in your area.

## Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its safety, please refer to the manufacturer's website for support and additional resources.

Thank you for prioritizing safety and compliance while using the Seater Head 11,60/.458R120. Your careful handling contributes to a safer reloading experience.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)