

Seater Head 11,60/.458-R125

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,60/.458-R125
- Manufacturer: TRIEBEL
- Product no.: EU2017558
- Mfr. No.: 3000054V-11.60-R125
- Diameter (in): 0.458
- Diameter mm: 11,60
- Radius: R125
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.60-R125

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 11,60/.458R125 by TRIEBEL. This guide provides important safety instructions to ensure the safe use and handling of this product. Please read this guide carefully before using the Seater Head to understand its features and how to use it safely.

General Safety Guidelines

- **Product Safety:**
 - Ensure that the Seater Head is used only for its intended purpose as specified in the product description.
 - Regularly inspect the Seater Head for any signs of wear or damage before use.
- **Enhanced Recalls:**
 - Stay informed about any recalls or safety notices related to the Seater Head. You can check for updates on the EU's Safety Gate platform.
- **Online Shopping:**
 - Ensure that you purchase the Seater Head from authorized retailers or directly from the manufacturer's website to guarantee product authenticity and safety.
- **Special Consumer Focus:**
 - This product is not intended for use by children. Keep it out of reach of minors.
- **EU Contact Point:**
 - For any safety inquiries or concerns, please refer to the manufacturer's website for guidance.
- **Rapid Alerts:**
 - Be aware that updates on unsafe products will be communicated through the Safety Gate system.

Specific Safety Precautions for Use

- Always wear appropriate safety gear when handling the Seater Head, including safety glasses and gloves.
- Do not exceed the recommended specifications for the Seater Head, such as diameter and radius, to avoid malfunction or accidents.
- Ensure that the Seater Head is properly attached to the reloading die before use.
- Avoid using the Seater Head in wet or damp conditions to prevent corrosion or electrical hazards.
- Do not modify the Seater Head or use it in a manner not specified by the manufacturer.
- Store the Seater Head in a dry, secure place when not in use to prevent damage and ensure safety.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading die is clean and free of debris.
- Carefully attach the Seater Head to the reloading die, following the manufacturer's instructions.

- Tighten the connection securely but avoid overtightening, which may cause damage.

2. Usage:

- Before seating a bullet, doublecheck that the Seater Head is properly aligned with the cartridge.
- Insert the cartridge into the die and gently lower the press handle to seat the bullet.
- Monitor the seating process to ensure that the bullet is seated correctly and at the desired depth.
- If you encounter resistance or unusual sounds during operation, stop immediately and inspect the Seater Head and die for any issues.

Disposal Instructions

- Dispose of the Seater Head responsibly in accordance with local waste disposal regulations.
- If the Seater Head is damaged or no longer usable, consider recycling it if possible.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for additional support and resources.