

Seater Head 11,86/.468-R35

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,86/.468-R35
- Manufacturer: TRIEBEL
- Product no.: EU2017559
- Mfr. No.: 3000054V-11.89-R035
- Diameter (in): 0.458
- Diameter mm: 11,86
- Radius: R35
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.89-R035

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 11,86/.468R35. This guide provides essential safety instructions and usage guidelines to ensure your safety and the optimal performance of the product. Please read this document carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible equipment and dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose, which is precise bullet seating in reloading applications.
- Follow all local laws and regulations regarding the use of reloading equipment and ammunition components.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling the Seater Head and during the reloading process.
- Ensure that your workspace is clean, welllit, and free from distractions while using the Seater Head.
- Avoid using excessive force when seating bullets, as this may lead to misalignment or damage to the Seater Head.
- Do not exceed the specified diameter or radius limits when using the Seater Head.
- Always follow the manufacturer's instructions for the reloading process to ensure safety and accuracy.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and disconnected from any power source.
- Carefully remove the existing seater head from the die.
- Align the Seater Head with the die and gently screw it in place, ensuring it is securely fastened.
- Check for proper alignment and functionality before proceeding.

2. Usage:

- Prepare your reloading components, including cases and bullets, in accordance with standard reloading practices.
- Insert a case into the reloading press and ensure it is properly positioned.
- Place the bullet on the case mouth and carefully lower the Seater Head onto the bullet.
- Apply consistent and gentle pressure to seat the bullet fully into the case.
- Inspect the cartridge for proper seating and alignment before proceeding to the next round.

Disposal Instructions

- Dispose of the Seater Head responsibly when it is no longer usable.
- Follow local regulations for the disposal of metal components and reloading equipment.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor. It is important to stay informed about product recalls and safety updates.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head 11,86/.468R35. Always prioritize safety and compliance with relevant regulations.