

Seater Head 12,04/.470-R6

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 12,04/.470-R6
- Manufacturer: TRIEBEL
- Product no.: EU2017560
- Mfr. No.: 3000054V-12.04-R006
- Diameter (in): 0.470
- Diameter mm: 12,04
- Radius: R6
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.04-R006

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,04/.470R6. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use of this product, please read and follow the safety guidelines outlined in this manual.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always follow the manufacturer's instructions and guidelines.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you encounter any issues or have concerns about the product, stop using it immediately and seek assistance.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Ensure that the working area is clean, dry, and free from clutter.
- Do not exceed the manufacturer's recommended specifications for use.
- Avoid using the product in wet or damp conditions.
- Be cautious of sharp edges and points when handling the Seater Head.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to select the appropriate seater head for your specific needs.

2. Installation:

- Ensure that your reloading die is clean and free from debris.
- Carefully insert the Seater Head into the reloading die, ensuring it is securely fitted.
- Tighten the locking mechanism to prevent movement during use.

3. Usage:

- Load the cartridge case into the reloading press according to the manufacturer's instructions.
- Adjust the seating depth as needed, ensuring that the bullet is aligned properly.
- Operate the reloading press slowly and steadily to achieve precise bullet seating.
- After use, clean the Seater Head to prevent residue buildup.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the product in household waste.
- If the product is damaged beyond repair, please recycle the materials where possible.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website or customer service resources.

Thank you for your attention to these safety guidelines. Your safety is our priority.