

Seater Head 12,04/.470-R31

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 12,04/.470-R31](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017561
- Mfr. No.: 3000054V-12.04-R031
- Diameter (in): 0.470
- Diameter mm: 12,04
- Radius: R31
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.04-R031

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,04/.470R31. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure safe and effective use, please carefully read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible equipment and dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including safety glasses, when using reloading equipment.
- Keep the work area clean and free from distractions to prevent accidents.
- Store the Seater Head in a safe place, out of reach of children and pets.
- Regularly inspect the Seater Head for any signs of wear or damage before use.

Specific Safety Precautions for Use

- **Compatibility:** Confirm that the Seater Head is compatible with your reloading dies. Use only with original Triebel dies.
- **Handling:** Handle the Seater Head with care to avoid personal injury or damage to the product.
- **Bullet Seating:** Ensure that the bullet is properly aligned before seating to avoid misfires or damage to the cartridge.
- **Pressure Testing:** Be aware of the maximum pressure ratings for the cartridges you are reloading. Exceeding these limits can lead to dangerous situations.
- **Ventilation:** Use the Seater Head in a wellventilated area to avoid inhaling any fumes or dust generated during the reloading process.

Instructions for Installation and Usage

1. Installation:

- Check that the reloading press is securely mounted and stable.
- Install the Seater Head into the reloading press according to the manufacturer's instructions.
- Ensure that the Seater Head is tightened properly to avoid movement during operation.

2. Usage:

- Prepare your brass cases and ensure they are clean and free from debris.
- Select the appropriate bullet for your cartridge.
- Insert the bullet into the case mouth and align it with the Seater Head.
- Slowly operate the reloading press to seat the bullet.
- Monitor the process closely to ensure proper seating depth and alignment.
- After seating, inspect the cartridges for any irregularities before proceeding to the next step.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations regarding metal waste.
- Do not dispose of the Seater Head in regular household waste. Check for recycling options in your area.

Contact Information for Further Support

For any safety inquiries, product support, or reporting unsafe products, please refer to the manufacturer's website or contact the designated EU contact point provided with your product documentation.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk