

Seater Head 12,04/.470-R35

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 12,04/.470-R35](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017562
- Mfr. No.: 3000054V-12.04-R035
- Diameter (in): 0.470
- Diameter mm: 12,04
- Radius: R35
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.04-R035

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,04/.470R35. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always handle the Seater Head with care to avoid injury.
- Ensure that you are using the Seater Head with compatible dies from Triebel Waffenwerkzeuge.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use protective eyewear when operating the Seater Head to prevent injury from debris.
- Ensure that your workspace is clean and free from hazards before starting your reloading process.
- Follow all manufacturer instructions for your reloading equipment to avoid accidents.
- Do not exceed the recommended specifications for bullet seating to maintain safety and accuracy.
- If you experience any difficulties during use, cease operation immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the correct Seater Head for your die set using the tool available on the manufacturer's website: www.triebelreloading.com.
- Carefully insert the Seater Head into the reloading die and secure it according to the manufacturer's instructions.

2. Usage:

- Before starting, ensure you have all necessary materials and equipment ready.
- Load the cartridge case into the reloading press as per the manufacturer's guidelines.
- Place the bullet on top of the cartridge case and gently lower the Seater Head to initiate seating.
- Apply consistent and steady pressure to achieve optimal bullet seating depth.
- After seating, check the cartridge for proper alignment and concentricity.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal waste.
- Do not dispose of the Seater Head in regular household waste.
- If the product is damaged or no longer usable, contact a local recycling center for proper disposal options.

Contact Information for Further Support

For any inquiries regarding the safety and use of the Seater Head, please consult the manufacturer's website or reach out to a qualified professional.

By following these safety instructions, you can ensure a safe and efficient reloading experience with the Seater

Head 12,04/.470R35. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk