

Seater Head 12,85/.505-R76

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 12,85/.505-R76
- Manufacturer: TRIEBEL
- Product no.: EU2017563
- Mfr. No.: 3000054V-12.85-R076
- Diameter (in): 0.505
- Diameter mm: 12,85
- Radius: R76
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.85-R076

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,85/.505R76, designed for precision bullet seating. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read all sections carefully before using the Seater Head.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that you are familiar with the operation of your reloading equipment before using this product.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before each use.
- Report any unsafe products or incidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the Seater Head.
- Ensure that your work area is clean and free of obstructions to prevent accidents during use.
- Do not exceed the recommended specifications for the Seater Head, including caliber and pressure limits.
- Avoid using damaged or worn components with the Seater Head, as this may lead to unsafe conditions.
- Always follow proper procedures for bullet seating to avoid misfires or accidents.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Gather all necessary tools and components for the reloading process.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Inspect the Seater Head for any visible damage.
- Insert the Seater Head into the appropriate die in your reloading press, ensuring a secure fit.

3. Usage:

- Adjust the Seater Head according to the specifications for your specific cartridge.
- Place a cartridge in the reloading press and engage the press to seat the bullet using the Seater Head.
- Monitor the seating depth and alignment to ensure optimal performance and accuracy.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal recycling.
- Do not dispose of the Seater Head in regular household waste.
- If the Seater Head is damaged beyond repair, consider recycling it at a designated facility that accepts metal products.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for additional resources and support.

Thank you for prioritizing safety while using the Seater Head. Your careful attention to these guidelines will help ensure a safe and productive reloading experience.