

Seater Head 12,90/.500-R31

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 12,90/.500-R31
- Manufacturer: TRIEBEL
- Product no.: EU2017565
- Mfr. No.: 3000054V-12.90-R031
- Diameter (in): 0.505
- Diameter mm: 12,90
- Radius: R31
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.90-R031

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,90/.500R31. This product is designed for precision bullet seating, ensuring optimal performance in your reloading process. To ensure safe and effective use of this product, please read the following safety instructions carefully.

General Safety Guidelines

- **Product Safety:** This product is designed to meet safety standards for nonfood items, ensuring safe use during bullet seating.
- **Enhanced Recalls:** In the event of safety concerns, recall notices will be issued, and remedies provided free of charge.
- **Online Shopping:** When purchased online, this product is subject to the same safety protections as those bought in physical stores.
- **Special Consumer Focus:** Extra precautions should be taken when this product is used by or around vulnerable groups, especially children.
- **EU Contact Point:** For any safety inquiries, please refer to the manufacturer's website for contact details.
- **Rapid Alerts:** Updates on unsafe products can be found on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Improper use may lead to injuries or product damage.
 - Ensure that the seater head is compatible with your reloading equipment.
- **Avoiding Hazards:**
 - Always follow the manufacturer's instructions for installation and usage.
 - Do not exceed the recommended specifications for the seater head.
 - Keep the product out of reach of children to prevent accidental injuries.
- **Protective Equipment:**
 - Wear safety goggles and gloves when handling reloading equipment.
 - Ensure a wellventilated area when using the product.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading press is clean and free of debris.
 2. Carefully remove the existing seater head if applicable.
 3. Insert the Seater Head 12,90/.500R31 into the reloading press, ensuring it is securely fastened.
 4. Verify that the seater head is properly aligned with the cartridge case holder.
- **Usage:**
 1. Adjust the seating depth according to your specific reloading needs.
 2. Insert the bullet into the cartridge case.
 3. Operate the reloading press smoothly, applying consistent pressure to seat the bullet.
 4. Check the alignment of the bullet after seating to ensure proper concentricity.
 5. Clean the seater head after use to maintain its precision and longevity.

Disposal Instructions

- **Disposal of Product:**
 - Dispose of the product in accordance with local regulations.
 - Do not dispose of brass components in regular waste. Check for recycling programs in your area.

- **Environmental Considerations:**

- Ensure that any waste materials are disposed of responsibly to minimize environmental impact.

Contact Information for Further Support

For any further inquiries regarding the Seater Head 12,90/.500R31, please visit the manufacturer's website for comprehensive support and resources.

Thank you for prioritizing safety while using the Seater Head. Your attention to these guidelines helps ensure a safe and effective reloading experience.