

Seater Head 12,90/.500-R42

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 12,90/.500-R42](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017566
- Mfr. No.: 3000054V-12.90-R042
- Diameter (in): 0.505
- Diameter mm: 12,90
- Radius: R42
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.90-R042

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,90/.500R42 by TRIEBEL. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use of this product, please read and follow the safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the Seater Head is compatible with your reloading dies.
- Store the Seater Head in a safe, dry location away from children and pets.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- If you encounter any issues during use, stop immediately and consult the manufacturer.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may lead to misalignment, resulting in inaccurate bullet seating.
- Use only as intended; do not modify the Seater Head.
- Handle with care to avoid injury from sharp edges.

- **Avoiding Hazards:**

- Always wear safety glasses when using reloading equipment.
- Ensure that your work area is clean and free from distractions.
- Do not exceed the recommended specifications for your reloading setup.

- **Age and Audience Specific Warnings:**

- This product is intended for use by individuals who are knowledgeable in reloading practices.
- Keep out of reach of children and inexperienced users.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading press is clean and properly set up.
2. Select the appropriate Seater Head for your specific die model using the tool available on the manufacturer's website www.tribelreloading.com.
3. Securely attach the Seater Head to your reloading die, following the manufacturer's guidelines.

- **Usage:**

1. Prepare your cartridges and ensure that all components are compatible.
2. Place the cartridge case into the reloading press.
3. Carefully lower the Seater Head onto the bullet, ensuring proper alignment.
4. Apply steady pressure to seat the bullet without forcing it.
5. Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Recycle materials where possible. Check with local authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the manufacturer's website or contact them directly through their EUbased contact point.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 12,90/.500R42. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk