

Seater Head 12,90/.500-R75

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 12,90/.500-R75
- Manufacturer: TRIEBEL
- Product no.: EU2017567
- Mfr. No.: 3000054V-12.90-R075
- Diameter (in): 0.505
- Diameter mm: 12,90
- Radius: R75
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.90-R075

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,90/.500R75. This guide provides essential safety instructions and usage guidelines to ensure the safe and effective operation of this product. Please read this manual carefully before use.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Store the Seater Head in a safe place, out of reach of children and vulnerable individuals.
- Inspect the Seater Head before each use for signs of wear or damage. Do not use if damaged.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or product failures to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Risk of injury from improper handling or misuse.
 - Risk of misalignment leading to inaccurate bullet seating.
- **Avoiding Hazards:**
 - Always handle the Seater Head with care and ensure it is securely attached to the reloading press.
 - Do not exceed the recommended specifications for the Seater Head.
 - Ensure the work area is clean and free from distractions while using the Seater Head.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and disconnected from power before installation.
- Remove any existing seater heads from the press.
- Align the Seater Head with the press and secure it according to the manufacturer's instructions.
- Verify that the Seater Head is properly installed and does not wobble.

2. Usage:

- Before seating bullets, verify the compatibility of the Seater Head with the cartridges you are using.
- Load the cartridge case into the press and ensure it is positioned correctly.
- Insert the bullet into the cartridge case.
- Gently press the handle of the reloading press to seat the bullet. Do not apply excessive force.
- After seating, check the alignment and concentricity of the cartridge.
- If any issues arise during usage, stop immediately and inspect the equipment.

Disposal Instructions

- Dispose of the Seater Head responsibly according to local regulations.
- Do not dispose of the Seater Head in regular household waste. Check for recycling options for metal components.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the appropriate support channels provided by Triebel Waffenwerkzeuge.

Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation (GPSR) while using the Seater Head. Your safety is our top priority.