

Seater Head 12,90/.500-R270

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 12,90/.500-R270](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017570
- Mfr. No.: 3000054V-12.90-R270
- Diameter (in): 0.505
- Diameter mm: 12,90
- Radius: R270
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.90-R270

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 12,90/.500R270. This product is designed for precision bullet seating and is made from highquality brass. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure safe use of the Seater Head by following all instructions.
- Always inspect the product for any signs of damage before use.
- Store the Seater Head in a dry and safe location, away from children and pets.
- Use the product only for its intended purpose as specified by the manufacturer.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when using the Seater Head.
- Keep hands and other body parts clear of moving parts during operation.
- Ensure that the workspace is clean and free from obstructions.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Use the correct seater head for your specific die and bullet type to avoid malfunctions.
- Follow all instructions provided on the manufacturer's website to ensure proper selection of the seater head.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials required for installation.
- Ensure that your workspace is clean and organized.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Inspect the Seater Head for any visible defects or damage.
- Install the Seater Head into the die according to the manufacturer's specifications.
- Ensure that the Seater Head is securely fastened in place.

3. Usage:

- Adjust the die according to your specific bullet and cartridge requirements.
- Insert the cartridge case into the die and align it properly.
- Gently lower the bullet into the case using the Seater Head.
- Apply consistent pressure to ensure proper seating of the bullet.
- After use, remove the cartridge and inspect for proper seating.

Disposal Instructions

- Dispose of any packaging materials responsibly by recycling where possible.
- If the Seater Head becomes damaged or is no longer usable, follow local regulations for disposal of metal products.

- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any safety inquiries or support related to the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com.

By following these guidelines, you can ensure safe and effective use of your Seater Head. Always prioritize safety and stay informed about best practices for reloading equipment. Thank you for your commitment to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk