

Seater Head 14,83/.577-R20

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 14,83/.577-R20
- Manufacturer: TRIEBEL
- Product no.: EU2017572
- Mfr. No.: 3000054V-14.83-R020
- Diameter (in): 0.577
- Diameter mm: 14,83
- Radius: R20
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-14.83-R020

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 14,83/.577R20. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully. It complies with the EU General Product Safety Regulation (GPSR) to provide you with essential safety information.

General Safety Guidelines

- Always read the manufacturer's instructions before using the Seater Head.
- Ensure that the product is suitable for your specific reloading setup.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use the product only for its intended purpose as described in the product specifications.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Wear appropriate safety gear, such as safety glasses and gloves, when handling and using the Seater Head.
- Ensure that the reloading press is securely mounted and stable before use.
- Do not exceed the recommended specifications for bullet seating to avoid potential hazards.
- Be cautious of sharp edges on the Seater Head during handling.
- Properly align the bullet and cartridge case to prevent jams or misfires.
- Store the Seater Head in a dry, safe place when not in use.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from your reloading die.
- Carefully insert the Seater Head into the die, ensuring a snug fit.
- Tighten the locking mechanism according to the manufacturer's specifications.

2. Usage:

- Prepare the cartridge case and bullet according to standard reloading procedures.
- Insert the cartridge case into the reloading press.
- Align the bullet with the cartridge case and lower the press handle smoothly.
- Monitor the bullet seating depth and adjust as necessary for your specific requirements.
- After use, clean the Seater Head to maintain its precision and performance.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal recycling.
- Do not dispose of the product in regular household waste.
- Ensure that any worn or damaged parts are properly discarded to prevent accidental injuries.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's website or contact their customer service team. Ensure you have the product details available for quicker assistance.

By following these guidelines, you can ensure a safe and effective experience with your Seater Head. Thank you for your attention to safety!