

Seater Head 14,88/.586-R106

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 14,88/.586-R106
- Manufacturer: TRIEBEL
- Product no.: EU2017574
- Mfr. No.: 3000054V-14.88-R106
- Diameter (in): 0.586
- Diameter mm: 14,88
- Radius: R106
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-14.88-R106

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 14,88/.586R106. This product is designed for precise and gentle bullet seating, ensuring optimal performance and accuracy. To ensure safe use and compliance with EU regulations, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is used in a well-ventilated area to avoid inhalation of any dust or particles.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Report any unsafe products or incidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Avoid using the Seater Head with incompatible dies or components.
- Do not force the Seater Head if it does not seat the bullet properly; check for obstructions or misalignments.
- Follow all local laws and regulations regarding ammunition reloading.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the press.
- Clean the threads of the press to ensure a secure fit.
- Carefully screw the Seater Head into the press until it is snug, but do not overtighten.
- Verify that the Seater Head is aligned properly with the bullet seating die.

2. Usage:

- Select the correct seater head using the tool on the manufacturer's website www.triebelreloading.com.
- Place the cartridge case in the reloading press.
- Insert the bullet into the case mouth, ensuring proper alignment.
- Activate the reloading press to seat the bullet gently.
- Inspect the seated bullet for proper alignment and depth.
- Repeat the process for additional cartridges, ensuring to check each one for consistency.

Disposal Instructions

- Dispose of the Seater Head in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.
- Consider recycling options for the brass material if applicable.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for further information and support resources.