

Seater Head 15,75/.600-R7

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 15,75/.600-R7
- Manufacturer: TRIEBEL
- Product no.: EU2017575
- Mfr. No.: 3000054V-15.75-R007
- Diameter (in): 0.600
- Diameter mm: 15,75
- Radius: R7
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-15.75-R007

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for purchasing the Seater Head 15,75/.600R7. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read the following safety instructions carefully.

General Safety Guidelines

- Ensure safe handling and use of the Seater Head by following these guidelines:
 - Always use the product in a wellventilated area.
 - Keep the Seater Head out of reach of children and vulnerable individuals.
 - Regularly inspect the Seater Head for any signs of damage or wear before use.
 - Follow all manufacturer instructions and recommendations for use.
 - Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- When using the Seater Head, please observe the following precautions:
 - Wear appropriate safety gear, including eye protection and gloves.
 - Avoid direct contact with the Seater Head's sharp edges.
 - Do not exceed the recommended specifications for bullet seating.
 - Ensure that the Seater Head is properly secured in the die before use.
 - Use only compatible cartridges and dies as specified by the manufacturer.
 - Do not modify the Seater Head in any way.

Instructions for Installation and Usage

- Follow these steps for proper installation and use of the Seater Head:

1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Remove any existing seater head from the die.
- Carefully insert the Seater Head into the die, ensuring it is seated properly.
- Secure the Seater Head according to the manufacturer's instructions.

2. Usage:

- Set up your reloading press according to the manufacturer's guidelines.
- Adjust the die to the desired seating depth.
- Insert the cartridge case into the press and ensure it is aligned correctly.
- Operate the press smoothly to seat the bullet.
- Inspect the completed cartridge for proper seating and alignment.

3. PostUse:

- Clean the Seater Head after use to remove any residue.
- Store the Seater Head in a dry place, away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of the Seater Head responsibly:
 - If the Seater Head is damaged beyond repair, follow local regulations for disposal of metal products.
 - Do not dispose of the Seater Head in regular household waste.
 - Consider recycling options available in your area.

Contact Information for Further Support

- For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact their customer support for assistance.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 15,75/.600R7. Thank you for your attention to safety.