

GRIP PLUG for GLOCK® - Gen 4 Glock Grip Plug, No Backstrap, 20, 21, 41

Keeps Dirt Out of Grip Frame

Snaps into the opening at the rear of the Glock® grip frame for a cleaner appearance, plus keeps dust, dirt, snow and water out of the gun. Creates a perfect location for adding extra weight to competition guns or to counter recoil on light, carry guns. Easily removed, does not alter gun. See specs for proper fit to your model of Glock.



Attributes

- Name: Gen 4 Glock Grip Plug, No Backstrap, 20, 21, 41
- Manufacturer: JENTRA
- Product no.: 463000013
- Mfr. No.: JP7
- Make: Glock
- Model: 20,21,41
- Delivery weight: 0.005kg
- Shipping height: 6mm
- Shipping width: 51mm
- Shipping length: 102mm
- UPC: 820103357364

Item details

Made in USA

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den GRIP PLUG für GLOCK® Gen 4
- English: GRIP PLUG for GLOCK® Gen 4 Safety Instruction Guide

Sicherheitshinweise für den GRIP PLUG für GLOCK® Gen 4

Einführung

Der GRIP PLUG für GLOCK® Gen 4 ist ein Zubehörteil, das dazu dient, die Öffnung am hinteren Ende des Glock® Griffrahmens zu schließen. Es trägt zu einem saubereren Erscheinungsbild bei und schützt die Waffe vor Staub, Schmutz, Schnee und Wasser. Bitte befolge die folgenden Sicherheitshinweise, um eine sichere Verwendung dieses Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stelle sicher, dass du die Waffe vor der Installation des GRIP PLUG entladen hast.
- Verwende den GRIP PLUG nur mit den kompatiblen GLOCK® Modellen: 20, 21, 41.
- Überprüfe regelmäßig den Zustand des GRIP PLUG, um sicherzustellen, dass er fest sitzt und keine Risse oder Beschädigungen aufweist.
- Halte das Produkt außerhalb der Reichweite von Kindern und anderen unbefugten Personen.
- Melde unsichere Produkte oder Unfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwende den GRIP PLUG nicht, wenn du Anzeichen von Beschädigungen oder Abnutzung bemerkst.
- Achte darauf, dass der GRIP PLUG korrekt installiert ist, um ein Verrutschen oder Herausfallen während der Verwendung zu vermeiden.
- Vermeide den Kontakt mit scharfen Gegenständen, um Beschädigungen am GRIP PLUG zu verhindern.
- Bei der Verwendung der Waffe, stelle sicher, dass der GRIP PLUG nicht die Funktionalität der Waffe beeinträchtigt.

Anweisungen zur Installation und Nutzung

1. Installation des GRIP PLUG:

- Stelle sicher, dass die Waffe entladen ist.
- Reinige die Öffnung am hinteren Ende des Griffrahmens.
- Setze den GRIP PLUG vorsichtig in die Öffnung ein, bis er fest sitzt.
- Überprüfe, ob der GRIP PLUG sicher und stabil installiert ist.

2. Nutzung der Waffe mit installiertem GRIP PLUG:

- Verwende die Waffe wie gewohnt.
- Achte darauf, dass der GRIP PLUG nicht die Bedienung oder Sicherheit der Waffe beeinträchtigt.
- Bei Bedarf kannst du den GRIP PLUG leicht entfernen, ohne die Waffe zu verändern.

Entsorgungsanweisungen

- Entsorge den GRIP PLUG gemäß den örtlichen Vorschriften für Kunststoffabfälle.
- Achte darauf, dass der GRIP PLUG nicht in die Umwelt gelangt und ordnungsgemäß recycelt wird, wenn möglich.

Kontaktinformationen für weitere Unterstützung

- Für Fragen oder Unterstützung zu diesem Produkt, wende dich bitte an den Hersteller oder den Händler, bei dem du das Produkt erworben hast.

Bitte beachte die oben genannten Sicherheitshinweise, um die sichere Verwendung des GRIP PLUG für GLOCK® Gen 4 zu gewährleisten.

GRIP PLUG for GLOCK® Gen 4 Safety Instruction Guide

Introduction

Thank you for choosing the GRIP PLUG for GLOCK® Gen 4. This product is designed to enhance the performance and appearance of your Glock firearm. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Ensure that the firearm is unloaded before installing or removing the grip plug.
- Always handle firearms with care and follow all safety protocols.
- Keep the grip plug and all firearm accessories out of reach of children.
- Regularly inspect the grip plug for any signs of wear or damage.
- If you notice any issues, discontinue use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Do not use the grip plug if it appears damaged or does not fit securely in the grip frame.
- Avoid exposing the grip plug to extreme temperatures or harsh chemicals.
- Ensure that the grip plug is properly seated before using the firearm.
- Be aware that adding weight to the grip may alter the balance and handling of the firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools if required for installation.

2. Installation:

- Locate the opening at the rear of the Glock® grip frame.
- Align the grip plug with the opening and gently press it into place until it snaps securely.
- Verify that the grip plug is seated properly and does not move when pulled.

3. Usage:

- Use the firearm as intended, ensuring that the grip plug remains secure during operation.
- Monitor the grip plug periodically for any signs of wear or loosening.

4. Removal:

- To remove the grip plug, gently pull it out from the rear of the grip frame.
- Ensure that the firearm is unloaded before attempting to remove the grip plug.

Disposal Instructions

- Dispose of the grip plug in accordance with local regulations.
- Do not dispose of the grip plug in regular household waste if it is damaged or contains hazardous materials.
- Consider recycling options if available.

Contact Information for Further Support

For any inquiries regarding the GRIP PLUG for GLOCK® Gen 4, please refer to the manufacturer's contact details provided with the product packaging or visit the manufacturer's website for more information.

By following these guidelines, you can ensure a safe and enjoyable experience with your GRIP PLUG for GLOCK® Gen 4. Thank you for your attention to safety.