

SCOPED RIFLE CASE 48" BLACK WITH BLACK TRIM

Brownells Scoped Rifle Case Case Shape Accommodates Scoped & Non-Scoped Rifles Removable, Adjustable Shoulder Strap w/ All Metal Swivels 2 1/4" Total Extra Thick Soft, Close Cell Padding Full Length Zipper w/ Pull Durable, Heavy-Duty Nylon Water-Resistant Outer Shell Zippered Accessory Pocket Soft, Fur Inner Lining For Maximum Protection Heavy-Duty Double Stitching



Attributes

- Name: SCOPED RIFLE CASE 48" BLACK WITH BLACK TRIM
- Manufacturer: BROWNELLS
- Product no.: 080001416
- Mfr. No.: BD240BRO
- Color: Black
- Size: 48
- Style: Rifle
- Delivery weight: 0.789kg
- Shipping height: 64mm
- Shipping width: 241mm
- Shipping length: 1,245mm
- UPC: 672352016123

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Brownells Scoped Rifle Case](#)

Safety Instruction Guide for Brownells Scoped Rifle Case

Introduction

Thank you for choosing the Brownells Scoped Rifle Case. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your rifle case. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure the rifle case is suitable for your specific rifle type (scoped or nonscoped).
- Always inspect the case for any visible damage before use.
- Keep the case out of reach of children and pets to prevent accidents.
- Do not overload the case beyond its intended capacity.
- Use the case only for its intended purpose—transporting firearms safely.
- Always follow local laws and regulations regarding firearm transportation.

Specific Safety Precautions for Use

- **Handling:** Always handle the rifle case with care. Avoid dropping or throwing the case, as this may compromise its integrity.
- **Zipper Use:** Ensure that the zipper is fully closed before transporting the case. Check that no items are caught in the zipper mechanism.
- **Padding:** The case features extra thick soft padding. Ensure that your rifle is securely placed within the padding to avoid movement during transport.
- **Shoulder Strap:** When using the adjustable shoulder strap, ensure that it is securely attached to the case to prevent accidental detachment.
- **Water Resistance:** While the outer shell is waterresistant, do not expose the case to prolonged wet conditions. Store in a dry place when not in use.

Instructions for Installation and Usage

1. **Unpacking:** Carefully remove the rifle case from its packaging. Inspect for any damage.
2. **Loading Your Rifle:**
 - Open the fulllength zipper.
 - Place your scoped or nonscoped rifle inside the case, ensuring it is positioned securely on the padded base.
 - Close the zipper fully, making sure that it is free from obstructions.
3. **Using the Shoulder Strap:**
 - Adjust the shoulder strap to your comfort level.
 - Attach the strap to the designated metal swivels on the case.
4. **Transporting the Case:**
 - Always carry the case using the shoulder strap or the handles provided.
 - Avoid dragging the case on the ground, as this may cause wear and tear.
5. **Storage:**
 - Store the case in a cool, dry place when not in use.
 - Avoid placing heavy objects on top of the case to maintain its shape and structure.

Disposal Instructions

When it comes time to dispose of your Brownells Scoped Rifle Case, please follow these guidelines: * Check local regulations for proper disposal methods of nylon and other materials. * If the case is damaged beyond repair, consider recycling if possible. * Do not burn the case, as it may release harmful substances.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please reach out to your local distributor or check the manufacturer's website for support resources.

Thank you for your attention to these safety instructions. Your safety and the integrity of your firearm are our top priorities. Enjoy using your Brownells Scoped Rifle Case!