

EZ SLIDE RACKER - Competition EZ Slide Racker for Glock

Springer Precision has designed these slide rackers in both carry/duty and competition models for Glock and Springfield XD-XDm handguns. The Carry/Duty models feature a lip off both sides of the slide to allow for easier grasp of the slide or to allow you to rack the slide off your belt, pocket or other objects. The Competition models have one approximately 1/2" lip off the left side of the slide for fast manipulations. Replaces your striker retainer plate.



Attributes

- Name: Competition EZ Slide Racker for Glock
- Manufacturer: SPRINGER PRECISION
- Product no.: 100013697
- Mfr. No.: BRNEZRACKGCOMP
- Make: Glock
- Model: Universal Handguns
- Delivery weight: 0.068kg
- Shipping height: 1mm
- Shipping width: 76mm
- Shipping length: 150mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: EZ SLIDE RACKER Safety Instruction Guide](#)

EZ SLIDE RACKER Safety Instruction Guide

Introduction

Thank you for choosing the EZ SLIDE RACKER Competition model designed for Glock handguns. This product has been carefully designed to enhance the ease of operation of your firearm. However, safety is paramount. This guide provides essential safety instructions, precautions, and proper usage to ensure a safe experience while using the EZ SLIDE RACKER.

General Safety Guidelines

- Always handle firearms with care and respect, treating every gun as if it is loaded.
- Ensure the firearm is unloaded before attaching or using the slide racker.
- Keep the slide racker and all firearms out of reach of children and unauthorized users.
- Regularly check the slide racker for any signs of wear or damage before use.
- Use the slide racker only for its intended purpose as specified in this guide.
- Be aware of your surroundings and ensure a safe environment when using your firearm.

Specific Safety Precautions for Use

- **Avoid Forceful Manipulation:** Do not apply excessive force when using the slide racker, as this may cause damage to the firearm or the racker itself.
- **Proper Grip:** Always ensure a secure grip on the slide racker to prevent slipping during operation.
- **Use Protective Gear:** Consider wearing eye protection when using firearms to protect against potential debris.
- **Keep Fingers Clear:** Always keep your fingers away from the trigger until you are ready to shoot.
- **Check Compatibility:** Ensure that the slide racker is compatible with your specific handgun model before use.

Instructions for Installation and Usage

1. Installation:

- Ensure your firearm is unloaded and pointed in a safe direction.
- Remove the striker retainer plate from your Glock handgun.
- Align the EZ SLIDE RACKER with the appropriate slots on the slide.
- Securely attach the racker in place, ensuring it is firmly seated.

2. Usage:

- To rack the slide, grasp the slide racker with your dominant hand.
- Apply pressure to the racker and pull it backward to cycle the slide.
- Release the slide racker, allowing the slide to return to its original position.
- If racking from a belt or pocket, position the racker on the edge of the object and pull back on the slide.

Disposal Instructions

- Dispose of the EZ SLIDE RACKER responsibly, in accordance with local regulations.
- Do not dispose of the racker in regular household waste.
- If the product is damaged or no longer in use, consider recycling options or contact a local waste management facility for guidance.

Contact Information for Further Support

For any questions or concerns regarding the EZ SLIDE RACKER, please refer to the manufacturer's contact information provided on the packaging or product insert. It is essential to have access to support for any safety inquiries or product issues.

By following these guidelines, you can ensure the safe use of the EZ SLIDE RACKER. Always prioritize safety and responsible firearm handling. Thank you for your attention to these important safety instructions.