

5700 ELITE METER WITH APPLIED BALLISTICS & LINK - 5700 ELITE WITH APPLIED BALLISTICS & LINK, OLIVE DRAB

A Whole Lot of Ballistic Computing Power - in the Palm of Your Hand

Kestrel's 5700 Elite Weather Meter with Applied Ballistics software is an upgrade of Kestrel's path-breaking but now-discontinued 4500 meter optimized specifically for the needs of long-range target shooters. The 5700 Elite measures up to 15 environmental parameters and lets you select either G1 or G7 ballistic coefficients (BC) when calculating bullet trajectory. It fits in the palm of your hand, yet offers the "Litz" (as in, noted ballistician Bryan Litz) measured BC library of over 225 bullets - the most extensive source of measured data for modern small arms bullets. Using its ballistics calibration feature, you can "train" your Kestrel 5700 Elite weather meter's Applied Ballistics software to match a specific rifle based on observed long-range impacts. The result is an even more accurate set data points you can rely on in future calculations. With such easy access to highly accurate BC data, you've got everything you need to make a pin-point precise trajectory calculation - in a hand-held wind meter. More of the Kestrel 5700 Elite's many features: Bluetooth LiNK to your Android or iOS smartphone Easy-to-use, intuitive user-interface screen navigation Improved screen resolution over earlier models - easier to see in varying light Screen switchable between white & red (NV - night vision) backlight Runs on one (1) AA battery Sealed battery compartment, so a battery leak will not fry your Kestrel's motherboard Multiple languages: English, French, German & Spanish Reinforced molded hard polymer shell & scratch/breakage-resistant viewing window Wait - it gets better! The Kestrel 5700 Elite Weather Meter comes with integrated Bluetooth technology, so both your real-time environmental and logged data can be transferred wirelessly and automatically to your smartphone, Mac, or PC. Yes, it's Android AND iPhone compatible, so whatever phone OS has your allegiance, the 5700 is ready to play nice with it. It will also connect via LiNK to a Bushnell CONX Rangefinder, enabling you to view results from the AB Kestrel right on your rangefinder. If you want to squeeze every last drop of performance from your rifle and your ammo, make sure you have a Kestrel 5700 Elite with Applied Ballistics software with you the next time you hit the range.



Attributes

- Name: 5700 ELITE WITH APPLIED BALLISTICS & LINK, OLIVE DRAB
- Manufacturer: KESTREL
- Product no.: 100034299
- Mfr. No.: 0857ALOLV
- Color: Olive Drab
- Delivery weight: 0.272kg
- Shipping height: 38mm
- Shipping width: 165mm
- Shipping length: 165mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for the Kestrel 5700 Elite Meter with Applied Ballistics & Link](#)
- [Español: Guía de Instrucciones de Seguridad del Kestrel 5700 Elite](#)
- [Norsk: Kestrel 5700 Elite Værmåler med Applied Ballistics & Link Brukerhåndbok for Sikkerhet](#)

Safety Instruction Guide for the Kestrel 5700 Elite Meter with Applied Ballistics & Link

Introduction

Thank you for choosing the Kestrel 5700 Elite Weather Meter with Applied Ballistics & Link. This guide provides essential safety instructions to ensure the safe and effective use of your device. Please read this document carefully before using the product.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the Kestrel 5700 Elite by following all instructions and guidelines outlined in this manual.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to your product. You can check for updates on the EU Safety Gate platform.
- **Online Shopping:** If purchased online, ensure that the seller complies with safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Keep it out of reach of children to prevent accidents.
- **EU Contact Point:** For safety inquiries, refer to the contact point provided by the manufacturer or retailer.
- **Rapid Alerts:** Be aware of the Safety Gate system for faster updates on unsafe products.

Specific Safety Precautions for Use

- **Environmental Conditions:** Do not operate the Kestrel 5700 Elite in extreme temperatures or conditions that may damage the device.
- **Battery Safety:** Use only the recommended AA battery. Ensure the battery compartment is sealed properly to avoid leaks.
- **Handling:** Handle the device with care. Avoid dropping or subjecting it to strong impacts.
- **Moisture Exposure:** Protect the device from excessive moisture. Do not immerse it in water.
- **Screen Care:** Clean the viewing window with a soft, dry cloth to avoid scratches or damage.

Instructions for Installation and Usage

- **Battery Installation:**
 1. Open the battery compartment.
 2. Insert one AA battery, ensuring the correct polarity.
 3. Close the battery compartment securely.
- **Turning the Device On/Off:**
 - Press the power button to turn the device on.
 - Press the power button again to turn it off.
- **Using the User Interface:**
 - Navigate the menu using the intuitive interface.
 - Select options by tapping the screen as indicated.
- **Connecting via Bluetooth:**
 - Enable Bluetooth on your smartphone or device.

- Follow the instructions on the Kestrel 5700 Elite screen to pair with your device.
- **Selecting Ballistic Coefficients:**
 - Access the Applied Ballistics software from the main menu.
 - Choose between G1 or G7 ballistic coefficients for your calculations.
- **Calibrating for Specific Rifles:**
 - Use the ballistics calibration feature to match the device to your specific rifle.
 - Follow the onscreen instructions to complete the calibration process.
- **Data Transfer:**
 - Use the integrated Bluetooth technology to transfer data to your smartphone, Mac, or PC.
 - Ensure your device is compatible and follow the pairing instructions.

Disposal Instructions

- **Battery Disposal:** Dispose of used batteries in accordance with local regulations. Do not throw batteries in regular trash.
- **Device Disposal:** When the Kestrel 5700 Elite is no longer in use, dispose of it responsibly. Follow local electronic waste disposal guidelines.

Contact Information for Further Support

For any questions or concerns regarding the Kestrel 5700 Elite Weather Meter, please refer to the manufacturer's support resources or your point of purchase.

By following these guidelines, you can ensure the safe and effective use of your Kestrel 5700 Elite Weather Meter with Applied Ballistics & Link. Thank you for your attention to safety.

Guía de Instrucciones de Seguridad del Kestrel 5700 Elite

Introducción

Gracias por elegir el Kestrel 5700 Elite con software Applied Ballistics. Este medidor de clima está diseñado para ofrecerte mediciones precisas y confiables en condiciones de tiro. Sin embargo, como con cualquier producto, es importante seguir las pautas de seguridad para garantizar un uso seguro y efectivo. Esta guía proporciona información sobre cómo usar el dispositivo de manera segura, así como instrucciones de instalación, uso y eliminación.

Directrices Generales de Seguridad

- Asegúrate de leer y comprender todas las instrucciones antes de usar el Kestrel 5700 Elite.
- Mantén el dispositivo fuera del alcance de los niños y de cualquier persona que no esté familiarizada con su uso.
- Utiliza el dispositivo solo para su propósito previsto, que es medir parámetros ambientales para la balística.
- Revisa el dispositivo regularmente para detectar cualquier daño o mal funcionamiento.
- Si el dispositivo se daña o presenta un mal funcionamiento, deja de usarlo inmediatamente y busca asistencia técnica.

Precauciones de Seguridad Específicas para el Uso

- **Condiciones Climáticas:** Evita usar el Kestrel 5700 Elite en condiciones extremas que puedan afectar su funcionamiento, como temperaturas muy altas o muy bajas.
- **Uso de la Batería:**
 - Utiliza solo una batería AA de alta calidad.
 - Asegúrate de que el compartimento de la batería esté sellado correctamente para evitar fugas.
 - No expongas la batería a temperaturas extremas o fuego.
- **Conexiones Bluetooth:**
 - Asegúrate de que la función Bluetooth esté activada solo cuando sea necesario.
 - No compartas tu información de conexión con personas no autorizadas.
- **Uso del Software:**
 - Sigue las instrucciones para calibrar el software de Applied Ballistics según las especificaciones de tu rifle.
 - No intentes modificar el software sin la supervisión adecuada.

Instrucciones para la Instalación y Uso

1. Instalación de la Batería:

- Abre el compartimento de la batería.
- Inserta una batería AA, asegurándote de que esté orientada correctamente.
- Cierra el compartimento de la batería.

2. Encendido del Dispositivo:

- Presiona el botón de encendido para activar el Kestrel 5700 Elite.
- Espera a que el dispositivo complete su autoevaluación.

3. Configuración Inicial:

- Selecciona el idioma deseado en la configuración.
- Conéctate a tu smartphone mediante Bluetooth para transferir datos.

4. Uso del Medidor:

- Selecciona los parámetros ambientales que deseas medir.
- Usa la función de calibración balística para ajustar la configuración según tu rifle.
- Toma lecturas y guarda los datos según sea necesario.

5. Cierre del Dispositivo:

- Apaga el dispositivo después de su uso.
- Guarda el Kestrel 5700 Elite en un lugar seguro y seco.

Instrucciones de Eliminación

- El Kestrel 5700 Elite y su batería deben ser desechados de acuerdo con las normativas locales sobre residuos electrónicos.
- No tires el dispositivo en la basura común.
- Busca un centro de reciclaje autorizado para desechos electrónicos en tu área.

Información de Contacto para Soporte Adicional

Para cualquier consulta o asistencia adicional sobre el Kestrel 5700 Elite, consulta el manual del usuario o visita el sitio web del fabricante.

Siguiendo estas pautas de seguridad, podrás disfrutar de una experiencia de uso segura y efectiva con tu Kestrel 5700 Elite. Asegúrate de mantenerte informado sobre cualquier actualización de seguridad o recordatorio a través de canales oficiales.

Kestrel 5700 Elite Værmåler med Applied Ballistics & Link Brukerhåndbok for Sikkerhet

Introduksjon

Takk for at du har valgt Kestrel 5700 Elite Værmåler med Applied Ballistics & Link. Denne håndholdte enheten er designet for å gi presise målinger av miljøparametere og ballistiske data. For å sikre trygg og effektiv bruk av produktet, vennligst les og følg sikkerhetsinstruksjonene i denne håndboken.

Generelle Sikkerhetsretningslinjer

- Sørg for at produktet brukes i henhold til produsentens spesifikasjoner.
- Hold enheten unna barn og sårbare grupper, med mindre de er under tilsyn av en voksen.
- Unngå bruk av enheten i ekstreme værforhold som sterk vind, kraftig regn eller snø.
- Kontroller produktet regelmessig for skader eller slitasje før bruk.
- Hvis enheten blir skadet, må den ikke brukes før den er reparert eller erstattet.

Spesifikke Sikkerhetstiltak for Bruk

- **Batterisikkerhet:**
 - Bruk kun den anbefalte typen AAbatteri.
 - Unngå å bruke batterier som er lekket eller skadet.
 - Fjern batteriene hvis enheten ikke skal brukes over lengre tid.
- **Bluetoothtilkobling:**
 - Sørg for at Bluetoothfunksjonen er aktivert på din smarttelefon før du kobler til.
 - Vær oppmerksom på at dataoverføring kan bli påvirket av hindringer som vegger eller andre elektroniske enheter.
- **Datainnsamling:**
 - Bruk alltid enheten i samsvar med gjeldende lover og forskrifter for datainnsamling.
 - Vær oppmerksom på personvernet til andre når du samler inn data.

Instruksjoner for Installasjon og Bruk

1. Batteriinstallasjon:

- Åpne batteridekselet på baksiden av enheten.
- Sett inn ett (1) AAbatteri i henhold til polaritetsmerkene (+ og -).
- Lukk batteridekselet forsvarlig.

2. Aktivering av enheten:

- Trykk på strømknappen for å slå på enheten.
- Vent til skjermen viser startopplysninger.

3. Bruk av Bluetooth LiNK:

- Aktiver Bluetooth på din smarttelefon.
- Åpne Kestrel LiNKappen og følg instruksjonene for å koble til enheten.

4. Måling av miljøparametere:

- Hold enheten i håndflaten din, og pek mot måleområdet.
- Vent til målingene stabiliserer seg før du registrerer dataene.

5. **Bruk av Applied Ballisticsprogramvaren:**

- Velg ønsket ballistisk koeffisient (G1 eller G7) i programvaren.
- Følg instruksjonene for å kalibrere enheten basert på spesifikke geværdata.

Avhendingsinstruksjoner

- Batterier må avhendes i samsvar med lokale forskrifter for farlig avfall.
- Enheten skal ikke kastes i vanlig søppel. Ta kontakt med lokale avfallshåndteringsmyndigheter for riktig avhending.
- Hvis enheten er skadet eller ikke kan repareres, må den returneres til produsenten for sikker avhending.

Kontaktinformasjon for Videre Støtte

For spørsmål eller mer informasjon om sikkerhet og bruk av Kestrel 5700 Elite Værmåler, vennligst kontakt produsentens kundeservice eller besøk deres offisielle nettside.

Vi takker for at du følger disse sikkerhetsinstruksjonene og ønsker deg en trygg og effektiv bruk av din Kestrel 5700 Elite Værmåler.