

MARKSMAN V4 SLIDE FOR GEN 3 G21 - ALPHA SHOOTING SPORTS

MARKSMAN V4 SLIDE GEN 3 G21, 45 ACP, BLACK

[Handgun Parts](#) > [Slide Parts](#) > [Slides](#)

A Custom Slide for Your Glock G21

In the world of Glock customization, the Glock G21 seems to get short-shrift, since everything's made for either the 9mm or .40 S&W variants of popular Glock handguns. Fans of the big-bore .45 ACP are left in the dust with their OEM models, but the Marksman V4 Slide designed for use in Gen 3 models of the G21 allows owners of these guns to step up with a clean, custom look. Each Marksman V4 G21 Slide is machined from 416 stainless steel in order to ensure long-lasting performance, and the rear of the slide is milled to accept a Trijicon RMR or a Holosun 507 red-dot sight. The slide is finished with a DLC PVD treatment, and other highlights include enhanced serrations for more positive manipulation of the slide, as well as a clean, attractive finish. The Marksman V4 G21 Slide is designed for use on Gen 3 Glock G21s or P80 PF45 handgun frames only.



Attributes

- Name: [ALPHA SHOOTING SPORTS MARKSMAN V4 SLIDE GEN 3 G21, 45 ACP, BLACK](#)
- Manufacturer: [ALPHA SHOOTING SPORTS](#)
- Product no.: 100036531
- Mfr. No.: G21MARKV4DLC
- Cartridge: 45 Auto (ACP)
- Finish: Black
- Model: 21
- Sights: RMR
- Style: Front & Rear Serrations
- Weapon type: Glock
- Delivery weight: 0.426kg
- Shipping height: 38mm
- Shipping width: 38mm
- Shipping length: 203mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for MARKSMAN V4 Slide for Gen 3 G21
- About Us

Safety Instruction Guide for MARKSMAN V4 Slide for Gen 3 G21

Introduction

Thank you for choosing the MARKSMAN V4 Slide for your Gen 3 Glock G21. This guide provides important safety instructions and guidelines to ensure the safe and effective use of your product. Please read this document carefully before installation and use.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure that the slide is properly installed before use.
- Regularly inspect your firearm and the slide for any signs of wear or damage.
- Only use the MARKSMAN V4 Slide with Gen 3 Glock G21 models.
- Store the firearm in a secure location, out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Be aware of your surroundings and ensure a clear and safe environment when handling your firearm.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before beginning the installation of the slide.
- Use only compatible sights (Trijicon RMR or Holosun 507) as specified in the product description.
- Avoid using excessive force during installation or manipulation of the slide.
- Do not modify the slide or firearm in any way that is not recommended by the manufacturer.
- If you experience any malfunction or irregularity during operation, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation of the MARKSMAN V4 Slide

- Ensure the firearm is unloaded.
- Remove the original slide from the Glock G21 by following the manufacturer's instructions.
- Align the MARKSMAN V4 Slide with the frame of the Glock G21.
- Carefully slide the MARKSMAN V4 Slide onto the frame until it is securely in place.
- Ensure that the slide is functioning properly by cycling it a few times before use.
- Attach the compatible sight (if desired) according to the manufacturer's instructions.

2. Usage of the MARKSMAN V4 Slide

- Always perform a safety check before firing.
- Ensure that the firearm is in good working order and that the slide is securely attached.
- Follow standard firearm safety practices while handling and using the firearm.
- Clean and maintain the slide regularly to ensure optimal performance.

Disposal Instructions

- Dispose of the MARKSMAN V4 Slide in accordance with local regulations regarding firearm accessories.
- Do not dispose of the slide in regular household waste.
- Contact local authorities for information on safe disposal methods for firearm accessories.

Contact Information for Further Support

For any questions, concerns, or safety inquiries regarding the MARKSMAN V4 Slide, please contact the manufacturer or refer to the product's official website for support resources.

By following these safety instructions, you can ensure a safe and enjoyable experience with your MARKSMAN V4 Slide. Always prioritize safety and responsible usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk